


OWNER'S MANUAL



TOHATSU

MD 40B2
MD 50B2
MD 75C2
MD 90C2
MD 115A2

OB No.003-11120-2AG2



WARNING

California Proposition 65

This engine contains or exhaust chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

ENOM00001-0



READ THIS MANUAL BEFORE USING THE OUTBOARD MOTOR. FAILURE TO FOLLOW THE INSTRUCTIONS AND SAFETY PRECAUTIONS IN THIS MANUAL CAN RESULT IN SERIOUS INJURY OR DEATH. KEEP THIS MANUAL IN A SAFE LOCATION FOR FUTURE REFERENCE.

Copyright © 2017 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

YOUR TOHATSU OUTBOARD MOTOR

ENOM00006-A

To You, Our Customer

Thank you for selecting a TOHATSU outboard motor. You are now the proud owner of an excellent outboard motor that will service you for many years to come.

This manual should be read in its entirety and the inspection and maintenance procedures described later in this manual should be followed carefully. Should a problem arise with the outboard motor, please follow the troubleshooting procedures listed at the end of this manual. If the problem persists, contact an authorized TOHATSU service shop or dealer.

Please always keep this manual together with the outboard motor as a reference to everyone who uses the outboard motor. If the outboard motor is resold, make sure the manual is passed on to the next owner.

We hope you will enjoy your outboard motor and wish you good luck in your boating adventures.

TOHATSU CORPORATION

ENOM00002-0

OWNER REGISTRATION AND IDENTIFICATION

Upon purchasing this product, be sure that the WARRANTY CARD is correctly and completely filled out and mailed to the addressee noted there on. This WARRANTY CARD identifies you as the legal owner of the product and serves as your warranty registration.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, YOUR OUTBOARD MOTOR WILL NOT BE COVERED BY THE APPLICABLE LIMITED WARRANTY, IF THIS PROCEDURE IS NOT FOLLOWED.

ENOM00003-0

PRE-DELIVERY CHECK

Be sure that the product has been checked by an authorized TOHATSU dealer before you take delivery.


ENOM00005-A

Serial Number


In the space below, please record the outboard motor's serial number (indicated both on the swivel bracket and on the cylinder block). The serial number will be needed when ordering parts, and when making technical or warranty inquiries.

Serial Number:

-40, 50




ENOF01300-1




ENOF01301-0

75, 90




ENOF01302-1




ENOF01303-0

115



ENOF01302-1



ENOF01305-0

Serial Number:

Date of purchase:

ENOM00007-0

NOTICE: DANGER/WARNING/CAUTION/Note

Before installing, operating or otherwise handling your outboard motor, be sure to thoroughly read and understand this Owner's Manual and carefully follow all of the instructions. Of particular importance is information preceded by the words "DANGER," "WARNING," "CAUTION," and "Note." Always pay special attention to such information to ensure safe operation of the outboard motor at all times.

ENOW00001-0

 DANGER

Failure to observe will result in severe personal injury or death, and possibly property damage.

ENOW00002-0

 WARNING

Failure to observe could result in severe personal injury or death, or property damage.

ENOW00003-0

 CAUTION

Failure to observe could result in personal injury or property damage.

ENON00001-0

Note

This instruction provides special information to facilitate the use or maintenance of the outboard motor or to clarify important points.


CONTENTS

1. GENERAL SAFETY INFORMATION	10
2. SPECIFICATIONS	12
3. PARTS NAME	18
4. LABEL LOCATIONS	23
5. INSTALLATION	29
1. Mounting the outboard motor on boat	29
2. Remote control device installation	32
3. Battery installation	33
4. Propeller installation	34
5. TOCS (Tohatsu Onboard Communication System) installation	36
6. Altitude adjustment kit requirement	37
6. PRE-OPERATING PREPARATIONS	38
1. Fuel handling	38
2. Fuel filling	39
3. Engine oil recommendation	40
4. Break-In	42
5. Warning system	43
7. ENGINE OPERATION	46
Before starting	46
1. Engine oil feeding	46
2. Fuel feeding	48
3. Starting the engine	49
4. Warming up the engine	54
5. Forward, reverse, and acceleration	54
6. Stopping the engine	57
7. Steering	59
8. Trim angle	60
9. Tilt up and tilt down	62
10. Shallow water operation	65
8. REMOVING AND CARRYING THE OUTBOARD MOTOR	67
1. Removing the outboard motor	67
2. Carrying the outboard motor	67
3. Trailering	68
9. ADJUSTMENT	70
1. Steering friction	70
2. Throttle grip friction	70
3. Remote control lever friction	70
4. Trim tab adjustment	71
10. INSPECTION AND MAINTENANCE	72
1. Daily Inspection	73
2. Periodic Inspection	79
3. Off-season storage	91
4. Pre-season check	94

5. Submerged outboard motor	94
6. Cold weather precautions	95
7. Striking underwater object.	95
8. Operation with multiple outboard motors	95
11. TROUBLESHOOTING	96
12. TOOL KIT AND SPARE PARTS	98
13. PROPELLER TABLE	100
14. EMISSION CONTROL SYSTEM INFORMATION.	101

INDEX

1 GENERAL SAFETY INFORMATION	1
.....	
2. SPECIFICATIONS	2
.....	
3. PARTS NAME	3
.....	
4. LABEL LOCATIONS	4
.....	
5. INSTALLATION	5
.....	
6. PRE-OPERATING PREPARATIONS	6
.....	
7. ENGINE OPERATION	7
.....	
8. REMOVING AND CARRYING THE OUTBOARD MOTOR	8
.....	
9. ADJUSTMENT	9
.....	
10. INSPECTION AND MAINTENANCE	10
.....	
11. TROUBLESHOOTING	11
.....	
12. TOOL KIT AND SPARE PARTS	12
.....	
13. PROPELLER TABLE	13
.....	
14. EMISSION CONTROL SYSTEM INFORMATION	14



GENERAL SAFETY INFORMATION

1 SAFE OPERATION OF BOAT

ENOM00009-0

As the operator/driver of the boat, you are responsible for the safety of those aboard and those in other boats around yours, and for following local boating regulations. You should be thoroughly knowledgeable on how to correctly operate the boat, outboard motor, and accessories. To learn about the correct operation and maintenance of the outboard motor, please read through this manual carefully.

It is very difficult for a person standing or floating in the water to take evasive action should he or she see a power boat heading in his/her direction, even at a slow speed. Therefore, when your boat is in the immediate vicinity of people in the water, the outboard motor should be shifted to neutral and shut off.

ENOW00005-0



WARNING

SERIOUS INJURY IS LIKELY IF A PERSON IN THE WATER MAKES CONTACT WITH A MOVING BOAT, GEAR HOUSING, PROPELLER, OR ANY SOLID DEVICE RIGIDLY ATTACHED TO A BOAT OR GEAR HOUSING.

ENOM00008-A

EMERGENCY STOP SWITCH

The Emergency Stop Switch will stall the outboard motor when the stop switch lanyard is pulled off. This stop switch lanyard has to be attached to the operator of the outboard motor to minimize or prevent injuries from the propeller in case the operator falls overboard.

It is operator's responsibility to use the Emergency Stop Switch Lanyard.

ENOW00004-A



WARNING

Accidental activation of the Emergency Stop Switch (such as the tether being pulled out in heavy seas) could cause passengers to lose their balance and even fall overboard, or it could result in loss of power in heavy seas, strong currents, or high winds. Loss of control while mooring is another potential hazard.

To minimize accidental activation of the Emergency Stop Switch, the 500 mm (20 inch.) stop switch lanyard is coiled and can be extended to a full 1300 mm (51 inch.).

ENOM00800-A

PERSONAL FLOATATION DEVICE

As the operator/driver and passenger of the boat, you are responsible to wear a PFD (Personal Floatation Device) while on the boat.

ENOM00010-0

SERVICING, REPLACEMENT PARTS & LUBRICANTS

We recommend that only an authorized service shop perform service or maintenance on this outboard motor. Be sure to use genuine parts, genuine lubricants, or recommended lubricants.

ENOM00011-A

MAINTENANCE

As the owner of this outboard motor, you should be acquainted with correct maintenance procedures following maintenance section of this manual (See page 72). It is the operator's responsibility to perform all safety checks and to ensure that all lubrication and maintenance instructions are complied with for safe operation. Please comply with all instructions concerning lubrication and maintenance. You should take the engine to an authorized dealer or service shop for periodic inspection at the prescribed intervals.

Correct periodic maintenance and proper care of this outboard motor will reduce the chance of problems and limit overall operating expenses.

Carbon Monoxide Poisoning Hazard

Exhaust gas contains carbon monoxide, a colorless and odorless gas which can be fatal if inhaled for any length of time.

Never start or operate the engine indoors or in any space which is not well ventilated.

Gasoline

Gasoline and its vapors are very flammable and can be explosive. Use extreme care when handling gasoline. You should be thoroughly knowledgeable on how to correctly handle gasoline by reading this manual.

SPECIFICATIONS

ENOM00810-A

MODEL FEATURE

Model		D40B2		D50B2
Type		ETO	EO	ETO
Transom heights	S	●	●	●
	L	●	●	●
Electrical start			●	●
Multi-function tiller handle			(●)	
Remote Control		●	(●)	●
Power Trim & Tilt		●		●
Mnual tilt			●	

●) These models can be purchased with remote rigging kit or multi-function tiller handle

Model		D75C2	D90C2
Type		EPTO	EPTO
Transom heights	L	●	●
	UL	●	●
Electrical start		●	●
Remote Control		●	●
Power Trim & Tilt		●	●
Oil auto-mixing		●	●

Model		D115A2
Type		EPTO
Transom heights	L	●
	UL	●
Electrical start		●
Remote Control		●
Power Trim & Tilt		●
Oil auto-mixing		●

ENOM00811-A

MODEL NAME EXAMPLE

D115A2 EPTOL

D	115	A2	E	P	T	O	L
Model description	Horse power	Product generation	Starter system	Steering system	Tilt system	Lubrication system	Shaft length
F= Four stroke D= Two stroke DI	-	A and up	E= Electrical start M= Manual start	P=Remote control (Pleasure) F=Tiller handle (Fisher)	T= Power trim&tilt G= Gas assist Blank= Manual tilt	O= Oil auto-mixing Blank= Oil Pre-mixing	S= Short 15 in L= Long 20 in UL= Ultra long 25 in

ENOM00601-A

40B2

2

Item		40B2	
		ETO (with RC)	
Overall Length	mm (in)	630 (24.8)	
Overall Width	mm (in)	355 (14.0)	
Overall Height S-L	mm (in)	1227 (48.3)	1354 (53.3)
Transom Height S-L	mm (in)	403 (15.9)	530 (20.9)
Weight	S kg (lb)	93.5 (206)	
	L kg (lb)	94.5 (208)	
Output	kW (ps)	29.4 (40)	
Max. Operating Range	rpm	5150–5850	
Idle Speed	rpm	700/800/900 *1	
Engine Type		Direct fuel injection	
Number of Cylinder		3	
Bore × Stroke	mm (in)	68 × 64 (2.68 × 2.52)	
Piston Displacement	mL (Cu in)	697 (42.5)	
Exhaust System		Through hub exhaust	
Cooling System		Water cooling	
Engine Lubrication		Oil injection	
Starting System		Electric starter motor	
Ignition System		Inductive Ignition	
Spark Plug		NGK IZFR6Q	
Alternator		12 V, 280 W (Max.)	
Trim Position		4	
Engine Oil		Genuine Motor Oil or recommended one	
Gear Oil		Genuine Gear Oil or API GL5, SAE #80 to #90, approx. 500 mL	
Fuel Tank Capacity	L (US gal)	25 (6.6)	
Engine Oil Capacity	L (US gal)	Approx. 2.0 (0.53)	
Gear Reduction Ratio		1.85 (13 : 24)	
Fuel		Unleaded regular gasoline : Pump posted 87 Octane (research octane rating of 91)	
Emission Control System		DFI (Direct Fuel Injection)	
Operator Sound Pressure (ICOMIA 39/94) dB (A)		84.0	
Hand Vibration Level (ICOMIA 38/94) m/sec2		—	

Remark: Specifications subject to change without notice.

*1: The idling speed can be set to any of the three rpm ranges, 700, 800 or 900. (See page 54)
Tohatsu outboard is power rated in accordance with ISO8665 (propeller shaft output).

ENOM00601-1

40B2

2

ItemMODEL		40B2		
		ETO (with multi-function tiller handle)	EO (with multi-function tiller handle)	EO (with RC)
Overall Length	mm (in)	775 (30.5)		630 (24.8)
Overall Width	mm (in)	355 (14.0)	345 (13.6)	
Overall Height S-L	mm (in)	1227 (48.3)	1354 (53.3)	
Transom Height S-L	mm (in)	403 (15.9)	530 (20.9)	
Weight	S kg (lb)	97.5 (215)	89.5 (197)	85.5 (188)
	L kg (lb)	98.5 (217)	90.5 (200)	86.5 (191)
Output	kW (ps)	29.4 (40)		
Max. Operating Range	rpm	5150–5850		
Idle Speed	rpm	700/800/900 *1		
Engine Type		Direct fuel injection		
Number of Cylinder		3		
Bore × Stroke	mm (in)	68 × 64 (2.68 × 2.52)		
Piston Displacement	mL (Cu in)	697 (42.5)		
Exhaust System		Through hub exhaust		
Cooling System		Water cooling		
Engine Lubrication		Oil injection		
Starting System		Electric starter motor		
Ignition System		Inductive Ignition		
Spark Plug		NGK IZFR6Q		
Alternator		12 V, 280 W (Max.)		
Trim Position		4	6	
Engine Oil		Genuine Motor Oil or recommended one		
Gear Oil		Genuine Gear Oil or API GL5, SAE #80 to #90, approx. 500 mL		
Fuel Tank Capacity	L (US gal)	25 (6.6)		
Engine Oil Capacity	L (US gal)	Approx. 2.0 (0.53)		
Gear Reduction Ratio		1.85 (13 : 24)		
Fuel		Unleaded regular gasoline : Pump posted 87 Octane (research octane rating of 91)		
Emission Control System		DFI (Direct Fuel Injection)		
Operator Sound Pressure (ICOMIA 39/94) dB (A)		84.0		
Hand Vibration Level (ICOMIA 38/94) m/sec2		3.8		—

Remark: Specifications subject to change without notice.
*1: The idling speed can be set to any of the three rpm ranges, 700, 800 or 900. (See page 54)
Tohatsu outboard is power rated in accordance with ISO8665 (propeller shaft output).

ENOM00602-0

50B2

2

Item	MODEL	50B2	
		ETO (with RC)	ETO (with multi-function tiller handle)
Overall Length	mm (in)	630 (24.8)	775 (30.5)
Overall Width	mm (in)	355 (14.0)	
Overall Height S-L	mm (in)	1227 (48.3)	1354 (53.3)
Transom Height S-L	mm (in)	403 (15.9)	530 (20.9)
Weight	S kg (lb)	93.5 (206)	97.5 (215)
	L kg (lb)	94.5 (208)	98.5 (217)
Output	kW (ps)	37 (50)	
Max. Operating Range	rpm	5150–5850	
Idle Speed	rpm	700/800/900 *1	
Engine Type		Direct fuel injection	
Number of Cylinder		3	
Bore × Stroke	mm (in)	68 × 64 (2.68 × 2.52)	
Piston Displacement	mL (Cu in)	697 (42.5)	
Exhaust System		Through hub exhaust	
Cooling System		Water cooling	
Engine Lubrication		Oil injection	
Starting System		Electric starter motor	
Ignition System		Inductive Ignition	
Spark Plug		NGK IZFR6Q	
Alternator		12 V, 280 W (Max.)	
Trim Position		4	
Engine Oil		Genuine Motor Oil or recommended one	
Gear Oil		Genuine Gear Oil or API GL5, SAE #80 to #90, approx. 500 mL	
Fuel Tank Capacity	L (US gal)	25 (6.6)	
Engine Oil Capacity	L (US gal)	Approx. 2.0 (0.53)	
Gear Reduction Ratio		1.85 (13 : 24)	
Fuel		Unleaded regular gasoline : Pump posted 87 Octane (research octane rating of 91)	
Emission Control System		DFI (Direct Fuel Injection)	
Operator Sound Pressure (ICOMIA 39/94) dB (A)		84.0	
Hand Vibration Level (ICOMIA 38/94) m/sec2		—	3.8

Remark: Specifications subject to change without notice.

*1: The idling speed can be set to any of the three rpm ranges, 700, 800 or 900. (See page 54)

Tohatsu outboard is power rated in accordance with ISO8665 (propeller shaft output).

ENOM00604-0

75C2, 90C2

2

Item	MODEL	75C2	90C2
		EPTO	
Overall Length	mm (in)	810 (31.9)	
Overall Width	mm (in)	508 (20.0)	
Overall Height L·UL	mm (in)	1540 (60.6)	1667 (65.6)
Transom Height L·UL	mm (in)	517 (20.4)	644 (25.4)
Weight	L·UL kg (lb)	150 (331)	153 (337)
Output	kW (ps)	55 (75)	66 (90)
Max. Operating Range	rpm	5150–5850	
Idle Speed	rpm	700/800/900 *1	
Engine Type		Direct fuel injection	
Number of Cylinder		3	
Bore × Stroke	mm (in)	86 × 72.7 (3.39 × 2.86)	
Piston Displacement	mL (Cu in)	1267	
Exhaust System		Through hub exhaust	
Cooling System		Water cooling	
Engine Lubrication		Oil injection	
Starting System		Electric starter motor	
Ignition System		Inductive Ignition	
Spark Plug		NGK IZFR6Q	
Alternator		12 V, 490 W (Max.)	
Trim Position		2	
Engine Oil		Genuine Motor Oil or recommended one	
Gear Oil		Genuine Gear Oil or API GL5, SAE #80 to #90, approx. 900 mL	
Fuel Tank Capacity	L (US gal)	—	
Engine Oil Capacity	L (US gal)	Approx. 4 (1.06)	
Gear Reduction Ratio		2.33 (12:28)	
Fuel		Unleaded regular gasoline : Pump posted 87 Octane (research octane rating of 91)	
Emission Control System		DFI (Direct Fuel Injection)	
Operator Sound Pressure (ICOMIA 39/94) dB (A)		81.7	
Hand Vibration Level (ICOMIA 38/94) m/sec2		—	

Remark: Specifications subject to change without notice.

*1: The idling speed can be set to any of the three rpm ranges, 700, 800 or 900. (See page 54)
Tohatsu outboard is power rated in accordance with ISO8665 (propeller shaft output).

ENOM00605-0

115A2

2

Item	MODEL	115A2	
		EPTO	
Overall Length	mm (in)	800 (31.5)	
Overall Width	mm (in)	495 (19.5)	
Overall Height L·UL	mm (in)	1640 (64.6)	1767 (69.6)
Transom Height L·UL	mm (in)	517 (20.4)	644 (25.4)
Weight	L·UL kg (lb)	178 (392)	181 (399)
Output	kW (ps)	85 (115)	
Max. Operating Range	rpm	5150–5850	
Idle Speed	rpm	700/800/900 *1	
Engine Type		Direct fuel injection	
Number of Cylinder		4	
Bore × Stroke	mm (in)	88 × 72.7 (3.46 × 2.86)	
Piston Displacement	mL (Cu in)	1768 (107.9)	
Exhaust System		Through hub exhaust	
Cooling System		Water cooling	
Engine Lubrication		Oil injection	
Starting System		Electric starter motor	
Ignition System		Inductive Ignition	
Spark Plug		NGK IZFR5J	
Alternator		12 V, 490 W (Max.)	
Trim Position		2	
Engine Oil		Genuine Motor Oil or recommended one	
Gear Oil		Genuine Gear Oil or API GL5, SAE #80 to #90, approx. 900 mL	
Fuel Tank Capacity	L (US gal)	—	
Engine Oil Capacity	L (US gal)	Approx. 6.7 (1.77)	
Gear Reduction Ratio		2.0 (13:26)	
Fuel		Unleaded regular gasoline : Pump posted 87 Octane (research octane rating of 91)	
Emission Control System		DFI (Direct Fuel Injection)	
Operator Sound Pressure (ICOMIA 39/94) dB (A)		83.3	
Hand Vibration Level (ICOMIA 38/94) m/sec2		—	

Remark: Specifications subject to change without notice.

*1: The idling speed can be set to any of the three rpm ranges, 700, 800 or 900. (See page 54)


Tohatsu outboard is power rated in accordance with ISO8665 (propeller shaft output).

PARTS NAME

ENOM00607-0

ETO (with multi-function tiller handle)/40B2, 50B2


3



ENOF01307-0

- | | | |
|--------------------------|-----------------------------|----------------|
| 1 Tilt Handle | 13 Clamp Bracket | 25 Spark Plug |
| 2 Top Cowl | 14 Thrust Rod | 26 Fuel Filter |
| 3 Hook Lever | 15 Throttle Grip | |
| 4 Water Check Port | 16 Shift Lever | |
| 5 Tilt Stopper | 17 Stop Switch | |
| 6 Water Plug | 18 Pilot Lamp | |
| 7 Anti-ventilation Plate | 19 Main Switch | |
| 8 Trim Tab | 20 Battery Cords | |
| 9 Propeller | 21 Power Trim & Tilt | |
| 10 Oil Plug (lower) | 22 Anode | |
| 11 Water Inlet | 23 Power Trim & Tilt Switch | |
| 12 Oil Plug (upper) | 24 Oil Tank | |

ENOM00608-0

ETO (with RC)/40B2, 50B2**3**


- | | |
|--------------------------|-----------------------------|
| 1 Tilt Handle | 13 Clamp Bracket |
| 2 Top Cowl | 14 Thrust Rod |
| 3 Hook Lever | 15 Power Trim & Tilt Switch |
| 4 Water Check Port | 16 Fuel Connector |
| 5 Tilt Stopper | 17 Battery Cords |
| 6 Water Plug | 18 Power Trim & Tilt |
| 7 Anti-ventilation Plate | 19 Anode |
| 8 Trim Tab | 20 Oil Tank |
| 9 Propeller | 21 Spark Plug |
| 10 Oil Plug (lower) | 22 Fuel Filter |
| 11 Water Inlet | |
| 12 Oil Plug (upper) | |

ENOF01308-0

ENOM00609-0

EPTO/75C2, 90C2


3



ENOF01309-0

- | | |
|--------------------------|-----------------------------|
| 1 Tilt Handle | 13 Thrust Rod |
| 2 Top Cowl | 14 Fuel Nipple |
| 3 Hook Lever | 15 Power Trim & Tilt Switch |
| 4 Water Check Port | 16 Battery Cords |
| 5 Water Plug | 17 Power Trim & Tilt |
| 6 Anti-ventilation Plate | 18 Anode |
| 7 Trim Tab | 19 Flushing Connector Cap |
| 8 Propeller | 20 Oil Tank |
| 9 Oil Plug (upper) | 21 Spark Plug |
| 10 Water Inlet | 22 Fuel Filter |
| 11 Oil Plug (lower) | |
| 12 Clamp Bracket | |

ENOM00610-0

EPTO/115A2**3**


ENOF01310-0

- | | |
|--------------------------|-----------------------------|
| 1 Tilt Handle | 15 Power Trim & Tilt Switch |
| 2 Top Cowl | 16 Battery Cords |
| 3 Hook Lever | 17 Power Trim & Tilt |
| 4 Water Check Port | 18 Anode |
| 5 Water Plug | 19 Flushing Connector Cap |
| 6 Anti-ventilation Plate | 20 Oil Tank |
| 7 Trim Tab | 21 Spark Plug |
| 8 Propeller | 22 Fuel Filter |
| 9 Oil Plug (upper) | |
| 10 Water Inlet | |
| 11 Oil Plug (lower) | |
| 12 Clamp Bracket | |
| 13 Thrust Rod | |
| 14 Fuel Nipple | |

ENOM00822-0

Remote control box & Fuel tank

3




ENOF00127-B

- | | |
|-----------------------|------------------------------------|
| 1 Control Lever | 9 Fuel Gauge |
| 2 Neutral lock arm | 10 Air Vent Screw |
| 3 PTT switch | 11 Fuel Tank Cap |
| 4 Free throttle lever | 12 Tab Lock |
| 5 Main switch | 13 Fuel Connector (Engine side) |
| 6 Stop switch | 14 Primer Bulb |
| 7 Stop switch lock | 15 Fuel Connector (Fuel tank side) |
| 8 Stop switch lanyard | |

■ LABEL LOCATIONS

ENOM00019-A

Warning label locations



ENOF01311-A

LABEL LOCATIONS

1. Warning label regarding owner's manual, top cowl, engine stop switch.



FNOF00005-W


- 2.** Warning regarding engine oil replenishment. (See page 40, 46)



3T1-72043-0

- 3.** Warning regarding engine oil replenishment(See page 37.40).

Affix this label near the outboard motor where it can be easily read.



3B7-72043-0

- 4.** Warning label regarding stop switch
(See page 59).




ENOE00005-P

- 5.** Indicator label regarding engine failure/malfunction (See page 43).)



FNOE00005-C

- Warning regarding high voltage, rotating parts, high temperature, fuel filter and fuel line.



3KY-72181-100

- 7.** Indicator label regarding engine failure/malfunction(See page 43).

stick this label at pace near the driver's seat where is easy to see.

[illegible]


3T5-72050-0

8. Warning label on engine stop switch.



ENOF00008-0

9. Warning regarding gasoline.



ENOF00005-E

10. Warning regarding gasoline (See page 38).



ENOF00005-L

11. Warning regarding gasoline (See page 38).




ENOF00005-M

12. Warning regarding gasoline (See page 38).




ENOF00005-F

13. Warning regarding fuel tank cap (See page 39).



ENOF00012-0

14. Warning tag regarding combination of fuel tank and primer bulb ass'y.



ENOF00005-T

15. Warning tag regarding instructions of the fuel tank cap (See page 39).



ENOF00011-0


ENOM00019-A

ECI (Emission Control Information) decal locations

40, 50

①	JAN	EMISSION CONTROL DECAL INFORMATION (MODEL YEAR) THIS ENGINE CONFORMS TO THE CALIFORNIA AND U.S. EPA EMISSION REGULATIONS FOR SPARK IGNITION MARINE ENGINES. THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARDS. REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS. THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE. [DISP.] FAMILY NAME: _____ MAX. POWER: _____ KW _____ HP 2-STROKE PART NO: _____	JUL
②	FEB		AUG
③ ④	MAR		SEP
⑤	APR		OCT
⑥	MAY		NOV
⑦ ⑧	JUN		DEC
⑨			
⑩			
⑪			
⑫			

- ① EMISSION CONTROL INFORMATION
- ② THIS ENGINE CONFORMS TO (MODEL YEAR) CALIFORNIA AND U.S. EPA EMISSION REGULATION FOR SPARK IGNITION MARINE ENGINES.
- ③ THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARD.
- ④ REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS.
- ⑤ THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE
- ⑥ DISPLACEMENT
- ⑦ FAMILY NAME
- ⑧ MAXIMUM POWER
- ⑨ OUTPUT
- ⑩ PART No.
- ⑪ TRADE MARK AND NAME OF MANUFACTURE
- ⑫ MODEL YEAR AND MONTH




ENOF01312-A

75, 90

①	JAN	EMISSION CONTROL DECAL INFORMATION (MODEL YEAR) THIS ENGINE CONFORMS TO THE CALIFORNIA AND U.S. EPA EMISSION REGULATIONS FOR SPARK IGNITION MARINE ENGINES. THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARDS. REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS. THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE. [DISP.] FAMILY NAME: _____ MAX. POWER: _____ KW _____ HP 2-STROKE PART NO: _____	JUL
②	FEB		AUG
③ ④	MAR		SEP
⑤	APR		OCT
⑥	MAY		NOV
⑦ ⑧	JUN		DEC
⑨			
⑩			
⑪			
⑫			

- ① EMISSION CONTROL INFORMATION
- ② THIS ENGINE CONFORMS TO (MODEL YEAR) CALIFORNIA AND U.S. EPA EMISSION REGULATION FOR SPARK IGNITION MARINE ENGINES.
- ③ THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARD.
- ④ REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS.
- ⑤ THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE
- ⑥ DISPLACEMENT
- ⑦ FAMILY NAME
- ⑧ MAXIMUM POWER
- ⑨ OUTPUT
- ⑩ PART No.
- ⑪ TRADE MARK AND NAME OF MANUFACTURE
- ⑫ MODEL YEAR AND MONTH



ENOF01312-B

1

2

3

4

5

6

7

8

9

10

11

12

MODEL YEAR

EMISSION CONTROL INFORMATION

DFI

JAN

THIS ENGINE CONFORMS TO MODEL YEAR CALIFORNIA AND U.S. EPA EMISSION REGULATIONS FOR SPARK IGNITION MARINE ENGINES.

JUL

FEB

THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARDS. REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS. THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE.

AUG

MAR

DISPLACEMENT: L FAMILY NAME:

SEP

APR

2-STROKE

OCT

MAY

MAXIMUM POWER: kW HP


NOV

JUN

PART No.

DEC

- 1 EMISSION CONTROL INFORMATION
- 2 THIS ENGINE CONFORMS TO (MODEL YEAR) CALIFORNIA AND U.S. EPA EMISSION REGULATION FOR SPARK IGNITION MARINE ENGINES.
- 3 THIS EQUIPMENT MEETS U.S. EPA EVAP STANDARDS.
- 4 REFER TO THE OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS.
- 5 THIS ENGINE IS CERTIFIED TO OPERATE ON GASOLINE.
- 6 DISPLACEMENT
- 7 FAMILY NAME
- 8 EMISSION LIMIT
- 9 OUTPUT
- 10 TRADE MARK AND NAME OF MANUFACTURE
- 11 PART No.
- 12 MODEL YEAR AND MONTH



ENOF01312-C

4

EPA Emissions Regulations

Outboards sold by Tohatsu America Corporation in the United States are certified to the United States Environmental Protection Agency as conforming to the requirements of the regulations for the control of air pollution from new outboard engines. This certification is contingent on certain adjustments being set to factory standards. For this reason, the factory procedure for servicing the product must be strictly followed and, wherever practicable, returned to the original intent of the design.

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any marine engine repair establishment or individual.

Engines are labeled with an Emission Control Information decal as permanent evidence of EPA certification.

Emissions Warranty Coverage
WARRANTY INFORMATION

Four Stroke Outboard Limited Warranty

Canadian and California residents who have purchased an outboard motor from a Canadian and California dealer receive additional warranty coverage for specific emissions related components. To fully understand your warranty coverage please read our standard warranty statement and the Emission Warranty Statement provided by your dealer.

INSTALLATION


ENOM00024-A

1. Mounting the outboard motor on boat

ENOW00006-B

WARNING

Before installing the outboard motor on the boat, hang the outboard motor with the hoist or equivalent device by attaching the engine hanger to the outboard. Use the hoist with allowable load is 250 kg (550 lbs) or above.



ENOF01313-0

ENOW00006-0

WARNING

Most boats are rated and certified in terms of their maximum allowable horsepower, as shown on the boat's certification plate. Do not equip your boat with an outboard motor that exceeds this limit. If in doubt, contact your dealer.

Do not operate the outboard motor until it has been securely mounted on the boat in accordance with the instructions below.

ENOW00009-0

WARNING


- Mounting the outboard motor without following this manual can lead to unsafe conditions such as poor maneuverability, lack of control or fire.
- Loose clamp screws and/or mounting bolts can lead to the release or displacement of the outboard motor, possibly resulting in lost of control and/or serious personal injury. Be sure that fasteners are tightened to the specified torque (30 Nm (3.0 kgf) 13 ft-lb). Check the fasteners for tightness from time to time.
- Be sure to use outboard mounting fasteners included in the outboard motor package or their equivalents in terms of size, material, quality and strength. Tighten fasteners to the specified torque (30 Nm (3.0 kgf) 13 ft-lb). Test cruise to check if fasteners are tightened securely.
- Outboard motor mounting must be performed by trained service person(s) using lift or hoist with sufficient capacity.

Outboard motor mounting must be performed by trained service person(s) using lift or hoist with sufficient capacity.

ENOM00025-0

Position ... Above keel line

Set engine at center of boat.



ENOF01141-0


1. Center of boat
2. Boat transom

ENOM00026-0

Transom matching

Be sure that the anti ventilation plate of the outboard motor is 10–30 mm (0.4–1.2 in) below the bottom of hull.

If the above condition cannot be met due to the shape of the bottom of your boat, please consult your authorized dealer.



ENOF01344-0

1. Bottom of hull
2. Anti ventilation plate

ENOW00007-0



CAUTION

- Before beginning the running test, check that the boat with maximum capacity loading floats on the water in a proper attitude. Check the position of water surface on the driveshaft housing. If the

water surface is near the bottom cowl-ing, in high waves, water may enter the engine cylinders.

- Incorrect outboard motor mounting height or existence of underwater object(s), such as hull bottom design, bottom surface conditions or underwater accessories, can cause water spray possibly reaching the engine through an opening of the bottom cowl-ing during cruising. Exposing the engine to such conditions for extended periods can lead to severe engine damage.

ENOM00830-B

Mounting bolts

Manual tilt type

40, 50

1. To attach the outboard motor to the boat, tighten the clamp screws by turning their handles.

Also, use the bolts to secure the out-board motor brackets on transom board.


Secure the outboard motor with a rope to prevent loss overboard.

ENON00002-0

Note


A rope is not included in the standard accessories.

75, 90, 115



ENOF00614-0

1. Bolt (12 mm × length 105 mm)
2. Washer (large diameter)
3. Nut
4. Washer (small diameter)



1. Top of transom

ENOW00008-A



CAUTION

- Mounting bolts should be installed with the bolt head at inside surface of the transom. Mounting bolts installed with the threaded end at the inside surface of the transom can cause personal injury.
- Tighten the bolts sufficiency, otherwise falling down of outboard could be happened.

ENON00003-0

Notes


1. Apply sealing agent, such as silicone sealed between the bolts and the transom board holes before tightening the bolts.
2. Be sure to tighten the mounting bolt nuts to the specified torque.
(30 Nm (3.0 kgf) 13 ft-lb)

ENOM00840-0

2. Remote control device installation

ENOW00850-0

Remote control box location



1. Shift cable
2. Throttle cable
3. Cable harness B

Install the remote control box in a position where it is easy to reach and operate the controls.

Make sure there are no obstacles that can interfere with the operation of the remote control cable.


ENOW00850-0

Remote control cable length

ENOW00100-A

⚠ CAUTION

Be careful not to loop the remote control cables to a diameter of 406 mm (16 inches) or less. Otherwise, it affects the service life of the cable.



ENOF00842-0

Measure the distance from the remote control box to the outboard motor where the remote control cable should be routed. Prepare a cable that is 300-450mm (11.8-17.7in) longer than the measured distance. Temporarily pull the cable along the intended cable route to check its length is sufficient.

Connect the remote control cable to the engine, then run the cable to the remote control box, making sure it is not sharply bent, too taut and free from obstructions that could interfere with steering.

ENOM00029-A

3. Battery installation

ENOW00012-0

⚠ WARNING

Battery electrolyte contains sulfuric acid and thus is hazardous, causing a burn if it comes in contact with your skin, or poisonous if swallowed.

Keep battery and electrolyte away from reach of children

When handling the battery, be sure to:

- Read all warnings shown on the battery case
- Prevent electrolyte from coming in contact with any part of your body. Contact can cause serious burn or, if it comes in contact with your eye, loss of sight. Use safety glasses and rubber gloves.

In case battery electrolyte comes in contact with:

- Skin, flush thoroughly with water.
- Eye, flush thoroughly with water, and then seek immediate medical treatment.

In case battery electrolyte is swallowed:

- Seek immediate medical treatment.

ENOW00013-A

⚠ WARNING

Battery generates explosive hydrogen gas. Be sure to:

- Charge the battery in a well-ventilated place.
- Place the battery away from any source of fire, sparks and open flames such as burners or welding equipment.
- Do not smoke near the battery when the battery is charging.
- Do not charge the battery when the electrolyte level is low. Otherwise, the battery will be damaged and may cause malfunction.

ENOW00014-0

⚠ CAUTION

- Make sure that the battery leads do not get stuck between the outboard motor and boat when turning, etc.
- The starter motor may fail to operate if the leads are incorrectly connected.
- Be sure to correctly connect the (+) and (-) leads. If not, the charging system will be damaged.
- Do not disconnect the battery leads from battery while the engine is operating, the electrical parts could be damaged.

- Always use a fully charged battery.

ENOW00015-0

CAUTION


Do not use a battery that is not recommended. Use of a battery not recommended can lead to poor performance of, and/or damage to, the electrical system.

ENON00006-A
Note

Recommended battery: 12V 100AH/5HR, 850 (Cold Cranking Amps (CCA), In case of cold weather: 12V120AH/5HR (1000CCA)) Specifications and features of batteries vary among the manufacturers. Consult the manufacturer for details.

* The battery should be purchased separately and is not supplied with the outboard motor.

1. Place the battery box in a convenient position away from possible water spray. Securely fasten both the box and the battery so they do not shake loose.
2. Connect the positive lead (+) to the positive terminal (+) of the battery, and then connect the negative lead (—). When disconnecting the battery always remove the negative lead (—) first. After connecting the positive terminal (+), securely place a cap on it to prevent short circuits.



ENOF00022-0

1. Battery cord (red)
2. Battery cord (black)

ENOM00123-0

4. Propeller installation

ENOW00085-A

WARNING


Do not begin propeller removal and installation procedure with spark plug caps attached, shift in forward or reverse, main switch at other than “OFF”, engine stop switch lock attached to the switch, and starter key attached, or engine could accidentally start leading to serious personal injury.

Disconnect battery cable if possible.

ENOW00085-0

! WARNING

Do not hold propeller with hand(s) when loosening or tightening propeller nut. Put a piece of wood block between propeller blade and anti-ventilation plate to hold propeller.



ENOF00084-B

ENOW00086-0

! CAUTION

- **Do not install propeller without thrust holder, or propeller boss could be damaged.**
- **Do not reuse split pin.**
- **After installing split pin, spread the pin apart to prevent it from falling out which could lead to the propeller coming off during operation.**


Propeller must be selected that will allow the engine to reach recommended maximum operating range during cruising.

Wide-open throttle rpm range
40 : 4750 – 5750 rpm
50 : 5150 – 5850 rpm
75/90 : 5150 – 5850 rpm
115 : 5150 – 5850 rpm

Genuine propellers are listed on PROPELLER TABLE of this manual (See page 85).

1. Remove the split pin, propeller nut and washer.
2. Remove the propeller and thrust holder.
3. Apply water proof grease to the propeller shaft before installing a new propeller.
4. Install the thrust holder, propeller, stopper, washer and propeller nut onto the shaft.


40, 50



ENOF01315-0

1. Propeller
2. Thrust holder
3. Stopper
4. Washer
5. Propeller nut
6. Split pin

75, 90




ENOF01335-0

1. Propeller
2. Thrust holder
3. Bush
4. Adaptor
5. Washer
6. Propeller nut
7. Split pin

7. Split pin


115



1. Propeller
2. Thrust holder
3. Bush
4. Stopper
5. Washer
6. Propeller nut
7. Split pin

5. Tighten the propeller nut to specific torque with holding the propeller by wood block. And align one of grooves to propeller shaft hole.

Propeller nut torque:

35 Nm (25 ft-lb, 3.5kgf-m)



6. Install a new split pin into the nut hole and bend it.

ENOM00971-0


5. TOCS (Tohatsu Onboard Communication System) installation

TOCS (Tohatsu Onboard Communication System) interface coupler can provide information regarding engine speed, fuel consumption, and various malfunction via an optional interface cable. Contact authorized Tohatsu dealer for more detail.

40, 50



75, 90, 115



ENOM00726-A

6. Altitude adjustment kit requirement

High altitude:

When engine operates at high altitude (over 1000m/3280ft) engine may need to have a high altitude kit installed. Otherwise, operating the engine at high altitude may increase its emissions and decrease fuel efficiency and performance. Contact authorized Tohatsu dealer for more detail.

PRE-OPERATING PREPARATIONS

ENOM00030-A

1. Fuel handling

ENOW000017-0



CAUTION

Use of improper gasoline can damage your engine. Engine damage resulting from the use of improper gasoline is considered misuse of the engine, and damage caused thereby will not be covered under the limited warranty.

ENOM00031-A

FUEL RATING

TOHATSU engines will operate satisfactorily when using a major brand of unleaded gasoline meeting the following specifications:

USA and Canada — having a posted pump Octane Rating of 87 (R+M)/2 minimum. Premium gasoline (92 [R+M]/2 Octane) is also acceptable. Do not use leaded gasoline.

Outside USA and Canada — Use unleaded gasoline with declared octane rating of 91 RON or over. Use of premium gasoline of 98 RON is also allowed.

ENOM00032-A

GASOLINES CONTAINING ALCOHOL

The fuel system components on your TOHATSU engine will withstand up to 10% ethyl alcohol (hereinafter referred to as the "ethanol"), content in the gasoline. But even if the gasoline in your area contains ethanol less than 10%, you should be aware of certain adverse effects that can occur. Increasing the percentage of ethanol in the fuel can also worsen these

adverse effects. Some of these adverse effects are caused because the ethanol in the gasoline can absorb moisture from the air, resulting in a separation of the water/ethanol from the gasoline in the fuel tank.

These may cause increased:

- Corrosion of metal parts
- Deterioration of rubber or plastic parts
- Fuel permeation through rubber fuel lines
- Starting and operating difficulties

If the use of gasoline containing alcohol is inevitable, or presence of alcohol is suspected in the gasoline, it is recommended to add a filter that has water separating capability, and check the fuel system for leaks and mechanical parts for corrosion and abnormal wear more frequently.

And, in case any of such abnormality is found, discontinue the use of such gasoline and contact our dealer immediately.

If the outboard motor will only be used infrequently, please see the remarks on fuel deterioration in the STORAGE chapter (P page 91) for additional information.

ENOW00020-1



CAUTION

When operating a TOHATSU engine on gasoline containing alcohol, storage of gasoline in the fuel tank for long periods should be avoided. Long periods of storage, create unique problems. In cars, alcohol blend fuels normally are consumed before they can absorb enough moisture to cause trouble, but boats often sit idle long enough for phase separation to take place. In addition, internal corrosion may take place during storage if alcohol has washed

protective oil films from internal components.

ENOW00018-D



WARNING

Fuel leakage can cause fire or explosion, potentially leading to severe injury or loss of life. Every fuel system part should be checked periodically, and especially after long term storage, for fuel leak, change of hardness of rubber, expansion and/or corrosion of metals. In case any indication of fuel leakage or degradation of fuel part is found, replace relevant part immediately before continuing operation.

ENOM00043-B

2. Fuel filling

ENOW00019-1



WARNING

Do not fill the fuel tank over capacity. The rise of gasoline temperature may cause gasoline to expand which, may leak through air vent screw when it is open. Leaking gasoline is a dangerous fire hazard.

ENOW00028-A



WARNING

Consult an authorized dealer for details on handling gasoline, if necessary.

Gasoline and its vapors are very flammable and can be explosive.

When carrying a fuel tank containing gasoline:

- Close the fuel tank cap and air vent screw of fuel tank cap, or gasoline vapor will be emitted through the air vent screw, creating a fire hazard.
- Do not smoke.

When or before refueling:

- Be sure to remove the static electricity charged in your body before refueling.
- The sparks due to static electricity may cause explosion of flammable gasoline.
- Stop the engine, and do not start the engine during refueling.
- Do not smoke.
- Be careful not to overfill fuel tank. Wipe up any spilled gasoline immediately.

When or before cleaning the gasoline tank:

- Dismount fuel tank from the boat.
- Place the fuel tank away from every source of ignition, such as sparks or open flames.
- Do the work outdoors or in a well ventilated area.
- Wipe off gasoline well immediately if spilled.

After cleaning gasoline tank:

- Wipe off gasoline well immediately if spilled.
- If the fuel tank is disassembled for cleaning, reassemble carefully. Imperfect assembly may cause a fuel leak, possibly leading to fire or explosion.
- Dispose aged or contaminated gasoline in accordance with local regulations.


ENOW00029-A



WARNING


When opening fuel tank cap, be sure to follow the procedure described below. Fuel could blast out through the fuel tank cap in case the cap is loosened by using another procedure when internal pressure of fuel tank is raised by heat from sources such as sun light.

1. Full open the air vent screw on the fuel tank cap and release internal pressure.



1. Air vent screw
2. Fuel tank cap

2. Loosen the tank cap until it contacts the tab lock and release internal pressure completely. After that, press down the tab lock and open the tank cap.
3. Fill the fuel carefully not to over flow.



4. After filling the tank, close the fuel tank cap until two clicks sound is heard.

ENOW00037-B


3. Engine oil recommendation

ENOW00022-A

CAUTION

The engine oil is drained for shipping from the factory. Be sure to fill the engine to the proper level before starting engine. (To

properly fill the engine with oil follow the instructions, See page 74)



1. Genuine of recommended engine oil
2. Filler lid
3. Oil tank cap

Use a genuine engine oil or recommended one. Refer to your Distributor. Will not recommended use of other two stroke engine oil.

ENOW0002A-A

CAUTION

Use of engine oils that do not meet these requirements will result in reduced engine life, and other engine problems.

ENOW00603-0

CAUTION

Do not mix different brands of oil. Mixing different brands of oil, or different types of oil even if the brand is the same, may cause gelling, resulting in possible filter screen blockage. This could result in serious engine damage because of impaired lubrication performance.

ENOW00022-0

CAUTION

The engine oil is drained for shipping from the factory. Be sure to fill the engine to the proper level before starting engine. (To properly fill the engine with oil follow the instructions in section 10 of this manual)

ENON00007-0

Note

Use of engine oils that do not meet these requirements will result in reduced engine life, and other engine problems.

ENOW00604-0

CAUTION

- In the unlikely event that gasoline by mistake is filled into the oil tank, drain the oil tank completely, and consult an authorized service shop for advice.
- Check the amount of oil in the oil tank visually before starting the engine. Running out of oil at sea is a cause for potential disaster.

The required amount of engine oil is automatically supplied from the oil tank, through the oil pump, according to the engine running conditions. Gasoline is fed over a separate feeding line.

ENOM00644-1

Replenishing oil in the engine oil tank.

1. Open the filler lid from the top cowl.
2. Open the oil tank cap.
3. Fill the oil tank with the genuine engine oil.
4. After replenishment of the oil tank, be sure to close the oil tank cap tightly.

ENOM00645-0


Oil pump air vent

Visually check whether there is air in the oil through the vinyl pipe connecting the oil tank with the oil pump. If present, Purge the air as follows:

40, 50

Loosen the air vent screw on the oil pump to purge the air, and tighten it when all air, as seen through the vinyl pipe on the oil pump side, has been purged.

40, 50



1. Air vent screw
2. From oil filter
3. Vinyl pipe

75, 90, 115

See page 47 for air removal from the oil lines.

ENON00608-0

Note

Wipe off any spilled oil with a rag, and dispose of it.

ENOM00033-A

4. Break-In

Your new outboard motor and lower unit require break-in for the moving components according to the conditions described in the following time table. Please refer to ENGINE OPERATION section (See page 46) to learn how to correctly start and operate the outboard motor.

ENOW00024-A

 DANGER

Do not operate the outboard motor in closed area or area with no forced ventilation.

Exhaust gas emitted by this outboard motor contains carbon monoxide that will cause death if inhaled continuously. Inhaling the gas initially causes symptoms such as feeling of sickness, drowsiness and headache.

During operation of the outboard motor:

- **Keep peripheral area well ventilated.**

- **Always attempt to stay on the windward side of emission.**

ENOW00023-1

 CAUTION

Operating the outboard motor without break-in can shorten service life.

If any abnormality is experienced during the break-in:

- **Discontinue the operation immediately.**
- **Have the dealer check the product and take proper action(s) if necessary.**

ENON00008-0

Note

Proper break-in allows outboard motor to deliver it full performance for longer service life.

	1-10 min	10 min - 2 hrs	2-3 hrs	3-10 hrs	After 10 hrs
Throttle Position	Idle	Less than 1/2 throttle	Less than 3/4 throttle	3/4 throttle	Full throttle available
Speed		Approx. 3000 rpm max	Full throttle run allowed for 1 min every 10 min	Approx. 4000 rpm. Full throttle run allowed for 2 min every 10 min	

ENOM00039-0

5. Warning system

If outboard motor encounters an abnormal condition of fault, the warning horn will emit a continuous beep or intermittent short beeps and the warning lamp (LED) will synchronize with the horn and engine speed will be limited (engine will not be stopped).

See next page for conditions which will lead to an abnormal condition or fault.

ENOM00040-B

Location of warning horn and lamp

■ Warning horn


RC model: Located inside the remote control.

Multi-Function tiller handle model: Located in the tiller handle. *Only for 40, 50

■ Warning lamp (LED)


RC model: Located in the tachometer.

Multi-Function tiller handle model: Located in the tiller handle. *Only for 40, 50



ENOF00852-0

1. Warning lamp



ENOF00851-0

1. Warning lamp

ENOM00041-C

Warning indicators, faults and remedy

Warning indicators				ESG	Description of faults or notice	Remark	Remedy
Sound							
	A lamp	B lamp	C lamp				
Continuous	ON	ON	ON	-	Normal system test when key on	1 second	
Continuous	-	-	-	High speed ESG	Engine speed exceeds maximum allowable RPM	Approx. 6,000 r/min	1
Intermittent (3 beeps for every 2 minutes)	Flash-ing	-	-	Low speed ESG	Low oil level		2
Continuous	-	Flash-ing	-	Low speed ESG	Cooling water temp. is high		3
Continuous	-	Flash-ing	-	Forced idling	Cooling water temp is abnormally high		3
-	-	-	Flash-ing	-	Battery voltage is low	Engine is stopped under 9V	4
-	-	Flash-ing	-	Low speed ESG	Battery voltage is low	Approx. 10V or less	4
-	Flash-ing	Flash-ing	Flash-ing	Low speed ESG	Malfunction of sensor		5
-	Flash-ing	Flash-ing	Flash-ing	Forced idling	Malfunction of sensor		5
-	Flash-ing	Flash-ing	Flash-ing	-	Malfunction of electrical part or sensor		5

High speed ESG (Electronic Safety Governor)

High speed ESG is a device to prevent over revolution of the engine. If the load to the engine becomes light for some reason, it runs at a higher speed than the usual. In such the case, the buzzer sounds and the ESG is activated not to ignite the spark plug, therefore, the engine speed varies and be controlled under 6000rpm.

Low speed ESG

Low speed ESG is a device to prevent the engine from getting damage. If the engine has problems regarding cooling water, oil pressure, and sensors, the low speed ESG is activated not to ignite the spark plug, and disable fueling therefore, the engine speed varies and be controlled under 3000rpm.

Remedy

1. Reduce the throttle to less than half opening, and move to safe place quickly, and stop the engine.
Check the propeller for bent or damaged blades.
Consult an authorized dealer if engine shows the same result even after replacing propeller with new one.
2. Move to safe place quickly, and stop the engine.
Check the engine oil level, and add engine oil if necessary.
3. Move to safe place quickly, and check the discharge of cooling water from the water check port at idle speed and stop engine.
Remove any foreign matter on the gear case and propeller if necessary. Consult an authorized dealer if no discharge of cooling water.
4. Charge or replace the battery.
5. Consult an authorized dealer.

ENOW00025-A

**CAUTION**

- **Low speed ESG ON: Engine speed will be limited to 3000 rpm, however you should not continue to run engine.**
- **High speed ESG ON: Engine speed will be limited to 6000 rpm and engine will run rough until throttle is reduced.**

ENGINE OPERATION


ENOM00042-0

Before starting

ENOW00022-A

CAUTION

The engine oil is drained for shipping from the factory. Be sure to fill the engine to the proper level before starting engine. (To properly fill the engine with oil follow the instructions. See page 74)



1. Genuine or recommended engine oil
2. Filler lid
3. Oil tank cap

ENOW00027-A

CAUTION

Before starting engine for the first time after reassembling engine or off-season storage, disconnect stop switch lock and crank approximately 10 times in order to prime the oil pump.

ENOM00656-A

1. Engine oil feeding

When the engine is new or have been left without operation for a long time, or just after the engine is overhauled, be sure to


execute the following operation for forcibly feeding the engine oil to the oil line before starting the engine.

ENOM00657-0


40, 50 type

- a. Disconnect the link rod by turning the rod snap interlocking with the oil pump as shown in the figure.
- b. Make sure that the oil pump control lever is set at open side position.
- c. Idle the engine for more than 30 minutes.
- d. Reset the link rod to the advancer arm.

40, 50



1. Rod snap
2. Link rod
3. Advancer arm
4. Cable joint
5. Throttle cable
6. R shaped pin
7. Nut



ENOF00652-0

1. Air vent screw
2. Link rod
3. From oil filter
4. Vinyl pipe
5. Open side
6. Control lever

ENOM00658-0

75, 90, 115 type (Electric oil pump)

Check to see by eyes if the oil line from the oil tank to the cylinder block ((1) to (4) in the 75, 90, 115 model) gets air inside or not. If there is air inside the oil line, remove it as follows.

● Oil tank-Filter (1)

- a. Fill the oil tank up with the specified oil.
- b. Remove the pipe of the filter inlet side at the part (A).
- c. Since the oil drains out with air, wait until air is completely discharged from the pipe. After checking for no air in the oil line, reconnect the pipe as it was and attach the clip to secure pipe connection.


● Filter-Oil Pump-Cylinder Block

[75, 90, 115: (2)-(4)]

- a. Turn on the key switch.
- b. Within 1 second after the buzzer stops sounding, remove the stop switch lock.


- c. Within 2 seconds after removing the stop switch lock, quickly repeat pulling and pushing back the stop switch knob 2 times.
- d. The buzzer sounds 3 times and the oil pump is actuated for about 1 minute for pressure feed of oil.
- e. When air is completely removed from the oil line, turn off the key switch.

75, 90, 115



ENOF00653-0

1. Look
2. Key switch
3. Stop switch knob



ENOF00654-0

1. Oil tank-Filter
2. Filter-Oil Pump
3. 75,90:Oil Pump-Cylinder Block (seven lines)
4. 115:Oil Pump-Cylinder Block (nine lines)

ENOM00044-B

2. Fuel feeding

ENOW00029-A

WARNING

When opening fuel tank cap, be sure to follow the procedure described below. Fuel could blast out through the fuel tank cap in case the cap is loosened by using another procedure when internal pressure of fuel tank is raised by heat from sources such as sun light.

ENOW00030-B

WARNING

When using EPA approval fuel tank, only use a primer bulb/hose assembly that has a Fuel Demand Valve (FDV) installed in the fuel hose or a sealing mechanism in the fuel connector as shown below.

FDV and fuel connector that has an sealing mechanism prevent pressurized fuel spillage when the fuel connector is connected to the engine.



ENOF00035-0

1. FDV in fuel hose
2. Sealing mechanism in fuel connector
3. Identification


Do NOT use a primer bulb/hose assembly that does not contain a Fuel Demand Valve or a sealing mechanism as shown below: otherwise fuel spillage may occur when the connector is connected to the engine.



ENOF00036-0


Do not connect fuel connector except when operating engine. Fuel leakage is a fire or explosion hazard, which can cause serious injury or death.

1. Full open the air vent screw on the fuel tank cap.




ENOF00029-0

1. Air vent screw
2. Fuel tank cap
2. Loosen the tank cap until it contacts the tab lock and release internal pressure completely. After that, close the tank cap until two clicks sound is heard.
3. Connect the fuel connector to the engine and fuel tank.



ENOF01316-0

1. Fuel connector
2. Pull
3. Insert



ENOF00861-A

1. Pull
2. Insert
4. Squeeze primer bulb until it becomes stiff to feed fuel to vapor separator. Direct arrow mark upward when priming.



ENOF00862-0

1. Engine side
2. Fuel tank side

Do not squeeze primer bulb with engine running or when the outboard motor is tilted up. Otherwise, fuel could overflow.

ENOM00045-A

3. Starting the engine


ENOW00036-A

CAUTION

When the engine is started in the test tank, to avoid over heating and water pump damage, be sure the water level is at least 10 cm (4 in.) above the anti ventilation plate.

Run the engine only at idling.

And be sure to remove the propeller, when starting the engine in the test tank. (See page 80)



ENOF00863-0

1. Over 10 cm (4 in.)

ENOW00036-0

CAUTION

Be sure to stop engine immediately if cooling water check port is not discharging water, and check if cooling water intake is blocked. Operating engine could lead to overheating potentially leading to engine damage. Consult an authorized dealer if the cause cannot be found.

ENOW00032-A

CAUTION

Do not hold turning starter motor for more than 5 seconds, or the battery may be consumed, potentially making the engine starting impossible and/or damaging the starter.

If cranking over 5 seconds fails to start engine, return main switch to "ON", and crank engine again after 10 seconds or more.

Do not try to crank after engine has started.

This model is provided with start in gear protection.


ENON00010-0

Note


Start-in-gear protection prevents engine from starting at other than neutral shift. In-gear starting of engine will move the boat immediately, potentially leading to falling down or causing passenger(s) to be thrown overboard.

Tiller handle type

1. Be sure to install the stop switch lock to the stop switch, and attach the stop switch lanyard securely to the operator or to the operator's PFD (Personal Flotation Device.)




1. Stop switch lock
2. Insert the main switch key.
3. Set the control lever in the Neutral position.



1. Shift lever

4. Set the throttle grip to START position.



ENOF00866-0

1. Throttle grip


ENON00613-A

Note

Turn the throttle grip to the "START" (fully closed), before turning the main switch key to "ON".

The wrong operation i.e. turn the main switch key to "ON" on the condition that the handle grip or accel lever is opened will be memorized by ECU (engine control unit). If this wrong operation has done repeatedly, it will have a possibility that the three warning lamps flash. In this case, turn the throttle grip to "START" (fully closed) and start the next operation after returning the main switch key to "OFF".

5. Turn the main switch key to ON position and confirm three warning lamps light up with buzzer sound and then go off.
6. Turn the main switch key to START position and release the key when the engine has started. The key returns to the original position, automatically.



1. Main switch key
2. Warning lamp


ENOW00032-1

CAUTION

Do not hold turning starter motor more than 5 seconds, or the battery may be consumed, potentially making the engine starting impossible and/or damaging the starter.


If cranking over 5 seconds fails to start engine, return main switch to "ON", and crank engine again after 10 seconds or more.

7. Check the cooling water from cooling water check port.



1. Idle port
2. Cooling water check port 40, 50

ENOF00664-0




ENOF00665-0

1. Idle port
2. Cooling water check port 75, 90, 115


Side mount RC type

1. Be sure to install the stop switch lock to the stop switch, and attach the stop switch lanyard securely to the operator or to the operator's PFD (Personal Flo-tation Device.)



ENOF00869-0


1. Stop switch lock
2. Insert the main switch key.
3. Set the control lever in the Neutral position. Do not raise the free throttle lever when starting the engine.



ENOF00870-0


1. Neutral (N)
2. Control lever
3. Fully opened (Forward)
4. Fully opened (Reverse)
5. Free throttle lever
6. Main switch key
7. Stop switch

4. Turn the main switch key to ON position and confirm three warning lamps light up with buzzer sound and then go off.



ENOF00851-0

1. Warning lamp
5. Turn the main switch key to START position and release the key when the engine has started. The key returns to the original position, automatically.



ENOF00871-0


1. ON
2. START
3. OFF

ENON00035-A

Note


The free throttle lever can not be raised when the control lever shift is in Forward or Reverse.

6. Check the cooling water from cooling water check port.



ENOF00664-0

1. Idle port
2. Cooling water check port 40, 50



ENOF00665-0

1. Idle port
2. Cooling water check port 75, 90, 115

ENOM00042-A

Emergency starting

*Only for 40, 50

ENOW00099-A


WARNING

When the emergency starter rope is used for starting engine;


- Start in gear protection does not work. Be sure to shift is at neutral position. Otherwise the engine will move the boat immediately and cause personal injury.
- Be careful that your clothes or other items do not get caught in the rotating engine parts.
- To prevent accident and injury by rotating parts, do not re-attach flywheel cover and the top cowl after the engine has been started.

- **Do not pull starter rope if any bystander is behind. The action can injure the bystander.**
- **Attach engine stop switch lanyard to clothing or any part of body like arm before starting engine.**

1. Remove the top cowl.




2. Remove the flywheel cover.



3. Insert the knotted end of the starter rope into the notch in the flywheel and wind the rope around the flywheel several turns clockwise.

4. Tie a loop in the another end of the emergency starter rope and attach socket wrench that is included in the tool kit.



ENOW00860-0

CAUTION

Be sure to keep the harness away from the rotation parts.

5. Be sure to install the stop switch lock to the stop switch, and attach the stop switch lanyard securely to the operator or to the operator's PFD (Personal Flo-tation Device.)
6. Set the control lever in the Neutral position.
7. Pull the starter handle slowly until you feel engagement, keep pulling till you feel less resistance. Then pull it quickly.
8. After engine starts, do not reinstall fly-wheel cover and top cowl.

ENOM00043-A

4. Warming up the engine

ENOW000932-0




Be sure to check that cooling water is coming out of the cooling water check port during warm up.

Warm the engine at low engine speeds for about

3 minutes : above 41°F (5 °C)


5 minutes at 2000 rpm : below 41°F (5 °C)

This allows the lubricating oil to circulate to all parts of the engine. Operating the engine without warm up shortens the engine's life.



ENOF00664-0

- 1. Idle port
- 2. Cooling water check port 40, 50



ENOF00665-0

- 1. Idle port
- 2. Cooling water check port 75, 90, 115

ENOM00044-0

Engine speeds

Idling speed after warming up.


Remark: In case of cold engine starting, idling speed is increased about 400 rpm for several minutes.

Clutch in (In gear)	Clutch off (Out of gear)
800 rpm	800 rpm

ENOM000880-0

Trolling engine speed control function

If the main switch key is pressed for 1 (one) second during idling or trolling operation, engine revolution change.



ENOF00876-0

Each time the main switch key is pressed in the above manner, engine speed changes as follows.

Starting
700rpm → 800rpm
↑ ↓
800rpm ← 900rpm

ENOM00046-A

5. Forward, reverse, and acceleration

ENOW00037-0



Before shifting into forward or reverse, make sure that boat is properly moored and outboard motor can be steered fully to

the right and left. Make sure that no swimmer(s) is ahead or astern of the boat.

ENOW00038-A

WARNING

- Attach other end of emergency stop switch lanyard to the operator's PFD (Personal Flotation device) or arm and keep it attached during cruising.
- Do not attach the tether to a part of clothing that can be torn easily when pulled.
- Arrange the tether so that will not be caught by any object when pulled.
- Be careful not to pull the tether accidentally during cruising. Unintentional stop of engine can cause loss of control of outboard motor. Rapid loss of engine power can lead to falling down or causing passenger(s) to be thrown overboard.

ENOW00042-0

WARNING

- Do not shift into Reverse during planing, or control will be lost leading to serious personal injury, boat may swamp, and/or hull may be damaged.
- Do not shift into Reverse during cruising, or control may be lost, falling down or causing passenger(s) to be thrown overboard. Leading to serious personal injury, and steering system and/or shifting mechanism may be damaged.

ENOW00861-0

WARNING

Do not shift at high boat speed, or control may be lost, falling down or causing passenger(s) to be thrown overboard. Leading to serious personal injury.

ENOW00862-0

CAUTION

Gear and clutch damage may occur if shifting at high engine speed.

Engine must be in the slow idle position before shifting is attempted.

ENOW00863-0

CAUTION

Idle speed may be higher during warming up of engine. If shifted to Forward or Reverse during warming up, it may be difficult to shift back to neutral. In such case, stop engine, shift to neutral, and restart engine to warm up.

ENON00014-0

Note

Frequent shifting to forward or reverse can accelerate wear or degradation of parts. In such case, replace gear oil earlier than the period specified.

ENOW00864-0

CAUTION

Do not increase engine speed unnecessarily when the shift is in neutral and reverse, or engine damage may occur.

ENOM00890-A

Tiller handle type

ENOW00865-0

CAUTION


Do not force to shift when the throttle grip is not in the fully closed position, otherwise, steering system and/or shifting mechanism may be damaged. The control lever is inoperative unless the throttle grip is in the fully closed position. (Multi-function tiller type)

ENOW00867-0

WARNING

Sudden acceleration and deceleration may cause passenger(s) to be thrown overboard or falling down.

7



ENOF00865-A

1. Shift lever

Forward

1. Turn the throttle grip to reduce engine speed.
2. When the engine reaches trolling (or idling) speed, quickly pull the shift lever to the Forward position.

Reverse

1. Turn the throttle grip to reduce engine speed.
2. When the engine reaches trolling (or idling) speed, quickly pull the shift lever to the Reverse position.


Acceleration

ENOW00867-0

WARNING


Sudden acceleration and deceleration may cause passenger(s) to be thrown overboard or falling down.

Open throttle grip gradually.



ENOF00878-0

1. Throttle grip



ENOF01119-0

1. Throttle grip


ENOM0900-0

Side mount RC type

ENOW00867-0

WARNING

Sudden acceleration and deceleration may cause passenger(s) to be thrown overboard or falling down.



1. Forward (F)
2. Neutral (N)
3. Reverse (R)
4. Fully opened (Forward)
5. Fully opened (Reverse)
6. Free throttle lever
7. Control lever
8. Lock button

Forward

1. Quickly push the control lever to the Forward (F) position 32° , where the gear is connected, while lifting up on the lock button located under the control lever grip.
2. Further forward motion will open the throttle.

Reverse

1. Quickly pull the control lever to the Reverse (R) position at 32° , where the gear is connected, while lifting up on the lock button located under the control lever grip.
2. Further rearward motion will open the throttle.


Acceleration

ENOW00867-A

CAUTION

Sudden acceleration and deceleration may cause passenger(s) to be thrown overboard or falling down.

Open control lever gradually.



1. Control lever
2. Main switch key

ENOM00049-A

6. Stopping the engine


ENOW00868-0

WARNING

Be careful not to remove engine stop switch lanyard from engine accidentally while boat is running. Sudden stop of engine can cause loss of steering control. It can also cause loss of boat speed, possibly leading the crew(s) and or objects on the boat to be thrown forward due to inertial force.


Tiller handle type

1. Turn the throttle grip to the slow position.



ENOF00866-0

1. Throttle grip
2. Put the shift lever in the Neutral position.
Run the engine for 2-3 minutes at idling speed for cooling down if it has been running at full speed.
3. Turn the main switch key to the OFF position or push the stop switch. (Do not forget to turn the key off).




ENOF00880-0

1. Throttle grip
2. Shift lever
3. Main switch key


Side mount RC type

1. Put the control lever in the Neutral position and run the engine for 2-3 minutes at idling speed for cooling down if it has been running at full speed.



ENOF00881-0

2. Turn the main switch key to the OFF position or push the stop switch. (Do not forget to turn the key off).



ENOF00882-0

1. Control lever
2. Main switch key

ENOW00869-0


WARNING

After stopping the engine:


- Close the air vent screw on the fuel tank cap.
- Disconnect the fuel connector of the engine and the fuel tank.
- Disconnect the battery cord, after each use.

Emergency engine stopping

Remove stop switch lock to stop the engine.



1. Stop switch
2. Stop switch lock



1. Stop switch
2. Stop switch lock

ENOM00910-0


Spare emergency stop switch lock

A spare emergency stop switch lock is provided in the tool bag.

When used as described, the emergency stop switch clip and emergency stop switch lanyard system stops the engine if the operator falls away from the controls.

When an operator falls into water, be sure to use emergency stop switch lock of the spare.

Be sure to confirm the spare stop switch lock is in the tool bag before begin to operate.



ENOF00891-0

ENOM00920-0

7. Steering

ENOW00870-0

WARNING

Sudden steering may cause passenger(s) to be thrown overboard or falling down.

7


Tiller handle type

Right turn

Move the tiller handle to the left

Left turn

Move the tiller handle to the right.



ENOF00892-0


Remote control type

Right turn

Turn the steering wheel to the right.

Left turn

Turn the steering wheel to the left.



ENOM00050-0

8. Trim angle

ENOW00043-A

! WARNING

- Adjust the trim angle when the engine is stopped.
- Do not put hand or finger in between outboard motor body and clamp bracket when adjusting trim angle to prevent injury in case the outboard motor body falls.
- Unsuitable trim position can cause loss of control of boat. When testing a trim position, run boat slow initially to see if it can be controlled safely.

ENOW00044-0

! WARNING

Excessive trim up or down may lead to unstable boat operation, potentially causing the steering difficulty that leads to accident during cruising.

- Do not cruise at high speed if improper trim position is suspected. Stop the boat and readjust trim angle before continuing cruise.


- For outboard motor model with PTT switch on the bottom cowl, do not operate the switch during cruising, or control of boat may be lost.

The trim angle of the outboard motor can be adjusted to suit the transom angle of the hull, and load conditions. Choose an appropriate trim angle that will allow the anti-ventilation plate to run parallel to the water surface during operation.

ENOM00052-0

Proper trim angle

The position of the thrust rod is correct if the hull is horizontal during operation.



ENOF00051-1

1. Perpendicular to the water surface

ENOM00053-0

Improper trim angle (bow rises too high)

Set the thrust rod lower if the bow of the boat rises above horizontal.



ENOF00052-0


ENOM00054-0

Improper trim angle (bow dips into the water)

Set the thrust rod higher if the bow of the boat is below horizontal.




ENOF00053-0

Manual Tilt type

ENOF00674-A

- 1. Thrust rod
- 2. Higher
- 3. Lower

Power Tilt type


ENOF00888-0

- 1. Thrust rod
- 2. Higher
- 3. Lower

Trim angle adjustment (Manual tilt type)

The transom angle adjustment

1. Stop the engine.
2. Shift into neutral.
3. Raise the outboard motor to the tilt up position.
4. Change the thrust rod position as following picture.



ENOF01238-1


1. Push in
2. Rise the stopper
3. Pull out
5. Reinstall the thrust rod securely.
6. Gently lower the outboard.

Trim angle adjustment (Power tilt type)

The transom angle adjustment

1. Stop the engine
2. Operate the Power Tilt switch and raise the outboard motor to the tilt up position.
3. Lock the tilt with the Tilt stopper.

4. Change the trim lock pin position as following picture.



ENOF01147-0

1. Snap pin
 2. Thrust rod
5. Reinstall the thrust rod securely.
6. Operate the Power Tilt switch and lower the outboard.

7

ENOM00060-A

9. Tilt up and down

ENOW00055-0

WARNING

Do not tilt up or down outboard motor when swimmer(s) or passenger is near to prevent them from being caught between outboard motor body and clamp bracket in case the outboard motor body falls.

ENOW00048-0

WARNING

When tilting up or down, be careful not to place your hand between the swivel bracket and the stern bracket. Be sure to tilt the outboard motor down slowly.

ENOW00056-A

WARNING

When tilting up outboard motor with fuel joint for over a few minutes, be sure to disconnect fuel hose, or fuel may leak, potentially catching fire.

ENOW00057-0

CAUTION

Do not tilt up outboard motor while engine operates, or no cooling water may be fed, leading to engine seizure due to overheating.

ENON00921-0

Note


Before tilting the outboard motor up, after stopping the motor leave it in the running position for about a minute to allow water to drain from inside the engine.

ENOM00062-A

Manual Tilt type (*40, 50 only)


Tilt up

Push the reverse lock lever down until it stops. (This is the tilt up position.) Now, tilt the outboard motor all the way up until it is locked in place.



ENOF00059-0


1. Reverse lock lever
2. Tilt up position
3. Tilt down position



ENOM00063-0

Tilt down

Pull the reverse lock lever upward until it stops. (This is the tilt down position.) Now, lift up the outboard motor slightly, and then allow gravity to lower it for you.



1. Reverse lock lever
2. Tilt up position
3. Tilt down position

ENOM00069-A

Power Trim & Tilt type


Tilt up

1. Operate the Power Trim & Tilt switch and tilt the outboard motor up.
2. Lock the tilt with the Tilt stopper after the outboard motor has been tilted up


Tilt down

1. Release the tilt stopper from the set-up position while slightly tilting up outboard motor.

2. Operate the Power Trim & Tilt switch and tilt the outboard motor down until the motor touches to the thrust rod.




40, 50




1. Tilt stopper

75, 90, 115



1. Tilt stopper

The outboard motor can also be tilted up and down using the switch provided under the bottom cowl.



It is possible to tilt up or down in spite of main switch "ON" or "OFF".

ENOM00940-0

Manual relief valve

If the battery is dead, and the power tilt switch thus inoperative, open the manual valve completely in the Manual direction. This will allow manual tilting of the outboard motor.

ENOW00872-0



WARNING

Make sure the manual relief valve is closed before operating the outboard motor. If the manual relief valve is not closed, the outboard motor will tilt up when operated in reverse.


ENOW00873-0



WARNING

Before opening the manual relief valve, make sure nobody is under the outboard motor. If the outboard motor is in the tilted up position, it will tilt down suddenly if the manual relief valve is loosened in the "Manual" direction.


40, 50



ENOF00070-1

1. POWER
2. MANUAL

75, 90, 115



ENOF00679-0

1. POWER
2. MANUAL

ENOM00068-A

10. Shallow water operation

ENOW00051-0

WARNING

During shallow water operation, be careful not to place your hand between the swivel bracket and the clamp bracket. Be sure to tilt the outboard motor down slowly.

ENOW00053-0


CAUTION

While in shallow water drive position, do not operate the outboard motor in Reverse. Operate the outboard motor at slow speed and keep the cooling water intake submerged.

ENOW00054-0

CAUTION

Do not overtilt outboard motor when driving shallow water, or air may be sucked through water inlet, potentially leading to engine overheating.




ENOF01144-A

1. Water inlet

Manual tilt type (*40, 50 only)


1. Shallow water running position:

Put the reverse lock lever in the tilt up position, and tilt up the outboard motor to put the outboard motor in the shallow water running position.




ENOF00059-0

1. Reverse lock lever
2. Tilt up position
3. Tilt down position



ENOF00668-0

2. Return to normal running position:
Put the reverse lock lever in the tilt down position, slightly lift up the outboard motor, and then put it down.




ENOF00059-0

1. Reverse lock lever
2. Tilt up position
3. Tilt down position


ENOM00069-A

Power Tilt type

1. Operate the Power Tilt switch and tilt the outboard motor up into desired shallow water running position.



ENOF00067-A



ENOF00067-0

REMOVING AND CARRYING THE OUTBOARD MOTOR

ENOM00070-A

1. Removing the outboard motor

ENOW00890-0

WARNING

Before installing the outboard motor on the boat, hang the outboard motor with the hoist or equivalent device by attaching the engine hanger to the outboard.


Use the hoist with allowable load is 250 kg (550 lbs) or above.

ENOW00064-0

CAUTION

Engine may be hot immediately after operating and could cause burns if touched. Allow engine to cool down before attempting to carry the outboard.

1. Stop the engine.
2. Remove the top cowl.
3. Disconnect the fuel connector, the remote control cables and the battery cords from the outboard motor.
4. Attach the hoist hooks to the engine hanger.
5. Remove the outboard motor from boat and completely drain the water from the gear case.



ENOF01313-0

ENOM00071-A

2. Carrying the outboard motor

ENOW00933-0

WARNING

Be sure to disconnect fuel connector except when operating engine.

Fuel leakage is a fire or explosion hazard, which can cause serious injury or death.

ENOW00065-0

WARNING

Close air vent screw of fuel tank before carrying or storing outboard motor and fuel tank, or fuel may leak, potentially catching fire.


ENOW00066-A

CAUTION

Do not give a shock to an outboard motor during transportation. It becomes a cause of breakage.

Keep the outboard motor in a vertical position when carrying.

The optional outboard motor stand is recommended for keeping the outboard motor vertical both during transport and storage.




ENOF01321-0

ENON00021-A

Note

- If the outboard motor must be laid down be sure drain the fuel and engine oil, then the port side faces down as shown in the drawing above.
- Elevate power unit 2 inches to 4 inches if traveling to avoid oil spillage.



ENOF00680-0

ENOM00072-A

3. Trailing

ENOW00072-0

CAUTION


Trailing in the tilted position may cause damage to the outboard motor, boat, etc.

ENOW00073-A

WARNING

Be sure to disconnect fuel connector except when operating engine.

Fuel leakage is a fire or explosion hazard, which can cause serious injury or death.



ENOF00075-1

ENOW00068-0

WARNING

Close air vent screw of fuel tank and fuel cock before carrying or storing outboard motor and fuel tank, or fuel may leak, potentially catching fire.

ENOW00071-0

CAUTION


The tilt support device supplied on your outboard motor is not intended for towing. It is intended to support the outboard motor while the boat is docked, beached, etc.

When transporting a boat on a trailer with the outboard motor still attached, disconnect the fuel line from the outboard motor beforehand and keep the outboard motor

in the normal running position or on a transom saver bar.

Tiller handle type

To prevent the outboard motor from moving when it is attached on a boat during transport on a trailer, properly tighten the steering friction lever (page 70).



1. Ground clearance should be provided sufficiently.
2. Transom saver bar

ENOW00067-0



WARNING

Do not go under outboard motor tilted up even if it is supported by support bar, or accidental fall of outboard motor could lead to severe personal injury.

ADJUSTMENT

ENOM00073-A

1. Steering friction


Tiller handle type (*40, 50 only)

ENOW00074-A

WARNING

Do not overtighten the steering friction lever it could result in difficulty of movement resulting in the loss of control causing an accident and could lead to severe injury.

Adjust this lever to achieve the desired steering friction (drag) on the tiller handle. Move lever towards (A) to tighten friction and move lever towards (B) to loosen friction.



1. Steering friction lever
2. Lighter
3. Heavier

ENOM00074-A

2. Throttle grip friction

*40, 50 only


ENOW00074-B

WARNING

Do not overtighten the throttle adjustment screw or it could result in difficulty of movement resulting in the loss of control

causing an accident and could lead to severe injury.

Friction adjustment of the throttle grip can be made with the throttle adjustment screw.



1. Throttle friction adjustment screw
2. Lighter
3. Heavier

ENOM00075-0

3. Remote control lever friction


ENOW00074-C

WARNING

Do not overtighten the remote control throttle friction adjustment screw or it could result in difficulty of movement resulting in the loss of control causing an accident and could lead to severe injury.

To adjust the friction of the remote control lever, turn the throttle friction adjustment screw on the front of the remote control. Turn clockwise to increase the friction and counter-clockwise to decrease it.

Side mount type



1. Throttle friction adjustment screw
2. Lighter
3. Heavier

ENOM00076-0

4. Trim tab adjustment

ENOW00076-1

WARNING

- Be sure that outboard motor is secured to transom or service stand, or accidental drop or fall of outboard motor could lead to severe personal injury.
- Be sure to lock outboard motor when it is tilted up, otherwise accidental fall of outboard motor could lead to severe personal injury.
- Do not go under outboard motor tilted up and locked, or accidental fall of outboard motor could lead to severe personal injury.


ENOW00075-1

WARNING

Inappropriate adjustment of trim tab could cause steering difficulty. After installing or readjusting trim tab, check if steering load is even.

the anti-ventilation plate.

- If the boat veers toward the left direct the trim tab towards A (left from rear of boat).
- If the boat veers toward the right direct the trim tab towards B (right from rear of boat).



1. Trim tab

ENON00022-A

Notes

- After adjustment securely tighten the trim tab fixing bolt.
- Check for looseness of the bolt and the trim tab at regular intervals.

If straight-line cruising can not be achieved, adjust the trim tab located under

INSPECTION AND MAINTENANCE

ENOM00077-0

Care of your outboard motor

To keep your outboard motor in the best operating condition, it is very important that you perform daily and periodic maintenance as suggested in the maintenance schedules that follow.

ENOW00077-0



CAUTION

- **Your personal safety and that of your passengers depends on how well you maintain your outboard motor. Carefully observe all of the inspection and maintenance procedures described in this section.**
- **The maintenance intervals shown in the checklist apply to an outboard motor in normal use. If you use your outboard motor under severe conditions such as frequent full-throttle operation, frequent operation in brackish water, or for commercial use, maintenance should be performed at shorter intervals. If in doubt, consult your dealer for advice.**
- **We strongly recommend that you use only genuine replacement parts on your outboard motor. Damage to your outboard motor arising from the use of other than genuine parts is not covered under the warranty.**

ENOM00703-0

1. Daily inspection

Perform the following checks and inspection before and after use.

ENOW00078-1



WARNING

Do not use outboard motor if any abnormality is found during pre-operation check otherwise it could result in severe damage to the motor or severe personal injury.

Item	Points to Check	Remedy
Fuel System	• Check the amount of fuel in the tank. • Check for dust or water in the fuel filter. • Check rubber pipes for oil leakage. • Fuel	Replenish Clean Replace
Fuel Tank Cap	• Check for crack, leakage, damage in the fuel tank cap. • Check for crack, damage in the gasket and tether. • Check for leakage at full close. • Check for ratchet performance.	Replace Replace Replace Replace
Lubrication System	• Check the amount of engine oil in the oil tank. • Check for dust or water in the oil filters.	Replenish Clean
Electrical Equipment	• Check the spark plugs for dirt, wear and carbon built-up. Spark plugs (30-40-50-75-90) NGK IZFR6Q (0.8 mm gap) (0.0315 in) Spark plugs (115) NGK IZFR5J (0.8 mm gap) (0.0315 in) • Check if the main switch functions normally. • Check if the battery electrolyte level and specific gravity are normal • Check for loose connections on battery terminal. • Check if the stop switch functions normally and make sure the lock plate is present. • Check cords for loose connections and damage.	Clean or replace Remedy or replace Replenish or recharge Retighten Remedy or replace Correct or replace
Throttle System	• Check if the magneto works normally when turning the throttle grip, and also check links for looseness.	Correct
Clutch and Propeller System	• Check if the clutch engages correctly when operating the Remote Control. (or Shift lever) • Check the propeller for bent or damaged blades. • Check if the propeller nut is tightened and the split pin is present.	Adjust Replace
Installation of Motor	• Check all the motor installation bolts with the boat. • Check the thrust rod installation.	Tighten Tighten
Power Trim & Tilt	• Check working of the tilt up and down of the motor.	
Cooling Water	• Check that cooling water is discharged from the cooling water check port after the engine has started.	
Tools and Spares	• To be prepare tools and spare parts for replacing spark plugs, propeller, etc. • Check if the spare rope is provided.	
Steering Devices	• Check working of steering handle and remote control.	

Item	Points to Check	Remedy
Other parts	• Check if the anode and trim tab are securely installed. • Check the anode and trim tab for corrosion and deformation.	Repair if necessary Replace

ENOM00082-A

Engine oil replenishing


ENOW00079-A

 CAUTION

- Do not add engine oil of brand and grade other than existing one. In case engine oil of other brand or grade is added, drain all oil and ask dealer for treatment.
- In case other than engine oil such as gasoline is put in the oil chamber, empty the chamber and ask dealer for treatment.
- When replenishing engine oil, be careful not to allow entry of foreign matters such as dust or water into oil chamber.
- Wipe off engine oil well immediately if spilled and dispose of it in accordance with local fire prevention and environment protection regulations.
- Do not replenish engine oil over upper limit. If overfilled, remove oil to upper limit. If engine oil is over the upper limit, it can leak and potentially lead to engine damage.

If the oil level is low, or at lowest mark, add recommended oil to the oil tank.

1. Open the filler lid from the top cowl.
2. Open the oil tank cap
3. Fill the oil tank with the genuine engine oil.
4. After replenishing of the oil tank, be sure to close the oil tank cap tightly.



1. Genuine of recommended engine oil
2. Filler lid
3. Oil tank cap

ENOM00083-A

Washing outboard motor

ENOW00081-0

 WARNING

Do not start engine without removing propeller, or accidentally turning propeller could cause personal injury.

ENOW00082-0

 WARNING

Never start or operate the engine indoors or in any space which is not well ventilated. Exhaust gas contains carbon monoxide, a colorless and odorless gas which can be fatal if inhaled for any length of time.

ENOW00920-0

⚠ CAUTION

When washing the outboard motor, be careful not to spray the water inside of the top cowl, especially electrical components.

ENON00026-0

Note

It is recommended to check chemical properties of water on which your outboard motor is regularly used.

If outboard motor is used in salt water, brackish water or water with a high acidic level, use fresh water to remove salt, chemicals or mud. And flush cooling water passage after every cruising or before storing outboard motor for long time. Before flushing, remove the propeller and the forward thrust holder.

ENOM00085-B

Flushing attachment (gear case)

40, 50

ENOW00922-0


⚠ CAUTION

To prevent the engine from starting when you are near the propeller, remove the stop switch lock.

1. Tilt down the outboard motor.
2. Remove the water plug from the gear case, and screw in the flushing attachment.
3. Attach the flushing attachment and connect a water hose. Turn on the water and adjust the flow (Be sure to seal the water inlet and sub water inlet, located in the gear case with tape)

4. Put the shift lever in the neutral position and start the engine. Continue flushing the outboard motor for 3 to 5 minutes at idling.
5. Stop the engine and water supply. Remove the flushing attachment and tape.


40, 50



ENOF01324-0

1. Flushing attachment

75, 90, 115.



ENOF01325-0

1. Flushing attachment

ENOM00085-C

Flushing attachment (bottom cowl)***75, 90, 115**

ENOW00921-0

CAUTION


Do not operate the engine when flushing the outboard motor with a flushing attachment as this can cause damage to the outboard motor.

ENOW00922-0

CAUTION

To prevent the engine from starting when you are near the propeller, remove the stop switch lock.

1. Tilt down the outboard motor.
2. Remove the flushing connector cap from the outboard motor, and screw in the flushing attachment.
3. Attach the flushing attachment and connect a water hose. Turn on the water and adjust the flow.
Continue flushing the outboard motor for 3 to 5 minutes
4. After the flushing, be sure to reattach the flushing connector cap.
5. Tilt up the outboard motor.

75, 90, 115

ENOF01326-0

1. Flushing attachment

ENOM00085-A

Flushing by test tank

ENOW00081-0

WARNING

Do not start engine without removing propeller, or accidentally turning propeller could cause personal injury.

ENOW00082-0

WARNING


Never start or operate the engine indoors or in any space which is not well ventilated. Exhaust gas contains carbon monoxide, a colorless and odorless gas which can be fatal if inhaled for any length of time.

ENOW00036-A

CAUTION

When the engine is started in the test tank, to avoid over heating and water pump damage, be sure the water level is at least 10 cm (4 in.) above the anti ventilation plate.

And be sure to remove the propeller, when starting the engine in the test tank. (See page 83)



ENOF00863-0

1. Over 10 cm (4 in.)

ENOM00950-0

Fuse replacement

ENOW00923-0

⚠ CAUTION

Before replacing a fuse, disconnect the battery cable from the battery negative (-) terminal. Failure to do so may cause a short-circuit.

ENOW00924-0



⚠ CAUTION

Never use a fuse with a rating that exceeds the specified rating as this could cause serious damage to the electrical system.



If a blown fuse is detected, try to determine the cause for this and correct it. If the cause for the problem is not corrected, the fuse will likely blow again.

If the fuse continues to blow, request an authorized Tohatsu dealer to inspect the outboard motor.

1. Stop the engine and disconnect the battery cable from the battery negative (-) terminal.
2. Remove the engine cover.
3. Remove the fuse box lid.
4. Remove the fuse and check it. If the fuse is blown, replace it with a fuse of the same specified rating. The outboard motor is supplied with spare fuses in the spare fuse holder.

40, 50.



ENOF01327-0

1. Blown fuse**75, 90**

ENOF01329-0

1. Blown fuse

115



ENOF01330-0

1. Blown fuse

ENOM00708-A

2. Periodic inspection

It is important to inspect and maintain your outboard motor regularly. At each interval on the chart below, be sure to perform the indicated servicing. Maintenance intervals should be determined according to the number of hours or number of months, whichever comes first.

For periodic inspection and maintenance, consult your servicing dealer.

Description		Inspection intervals				Inspection procedure	Remarks
		First 20 hours of 1 month	Every 50 hours of 3 months	Every 100 hours of 6 months	Every 200 hours of 1 year		
Fuel System/ Compression System	Fuel filter		•	•	Replace ●	Check and clean or Replace if necessary.	Entire cartridge
	High pressure fuel filter ^{*1}				Replace ●	Replace every 200 hrs or 2 years	
	Piping/Hoses ^{*2}	•	•	•	Replace ●	Check and clean or Replace if necessary.	
	Fuel tank ^{*2}	•	•	•	•	Clean	Including filter
	Fuel tank cap ^{*2}	•	•	•	•	Check and clean or Replace if necessary.	
	Fuel pump ^{*1}	•	•	•	•	Check and clean or Replace if necessary.	
	Air filter ^{*1}			•	•	Check and clean or Replace if necessary.	
	Drive belt ^{*1}			•	•	Check and Replace if necessary.	
	Fuel Pressure ^{*1}			•	•	Check and replace defective parts if necessary.	
	Air Pressure ^{*1}			•	•	Check and replace defective parts if necessary.	
Ignition	Spark plug	•		•	•	Remove carbon deposits or Replace if necessary.	0.8–0.9 mm (0.031–0.035 in)
Starting System	Starter motor ^{*1}			•	•	Check for salt deposits and the battery cable condition.	
	Battery	•	•	•	•	Check installation, fluid quantity, gravity.	
Engine oil system	Oil tank	•		•	•	Check and clean or Replace if necessary.	
	Oil pipe	•		•	•		
	Oil filter	•		•	•	Check and clean or Replace if necessary.	
Lower Unit	Propeller	•	•	•	•	Check for bent blades, damage, wear.	
	Gear oil	Replace ●		Replace ●	Replace ●	Change or replenish-oil and check for water leaks.	
	Water pump ^{*1}		•	•	•	Check for wear or damage.	Replace impeller every 12 months.
Thermostat ^{*1}				•	•	Check and Replace if necessary.	
Power trim & tilt ^{*1}		•		•	•	Check & replenish oil, manually operate	
Warning system ^{*1}			•	•	•	Check function	
Bolts and Nuts		•	•	•	•	Retighten	

Description	Inspection intervals				Inspection procedure	Remarks
	First 20 hours of 1 month	Every 50 hours of 3 months	Every 100 hours of 6 months	Every 200 hours of 1 year		
Sliding and Rotating Parts. Grease Nipples	•	•	•	•	Apply and pump in grease.	
Outer Equipment	•	•	•	•	Check for corrosion.	
Anode		•	•	•	Check for corrosion and deformation.	Replace if necessary.

*1: Have this handled by your dealer
*2: In USA, you have to use EPA approved part (See page 48).

ENON00030-0

Note

Your outboard motor should receive careful, and complete inspection at 300 hours. This is the best time for major maintenance procedures to be carried out.

ENOM00093-A

Fuel filters and fuel tank cleaning

ENOW00093-A

⚠ WARNING

Gasoline and its vapors are very flammable and can be explosive.


- Do not start this procedure while engine is operating or hot even after stopping it.
- Place fuel filter away from every source of ignition such as sparks or open flames.
- Wipe off gasoline well immediately if spilled and dispose of it in accordance with local fire prevention and environment protection regulations.
- Install fuel filter with all related parts in place, or fuel leak could occur, leading to catching fire or explosion.
- Check fuel system regularly for leakage.
- Contact authorized dealer for fuel system services. Services by unqualified person could lead to engine damage.

Fuel filters are provided inside the fuel tank and engine.

ENOM00094-0

Fuel filter (for engine)

1. Check in the cup for water and debris.



1. Body
 2. O-ring
 3. Filter
 4. O-ring
 5. Cup
 6. Arrow to indicate fuel flow direction
2. If present, disconnect hoses from the fuel connector (male) and the fuel pump.
 3. Remove the cup, filter and O-rings from the fuel filter body.
 4. Check the wear and clogging for each parts, and replace if necessary.
 5. Remove fuel and any water or debris from the cup, filter and hoses.
 6. Reassemble all parts.


ENOM00096-A

Fuel filter (for fuel tank)

Water or dirt in the fuel tank will cause engine performance problems.

Check and clean the tank at specified times or after the outboard motor has been stored for a long period of time (over three months).

1. Remove the fuel pickup elbow of the fuel tank by turning it counterclockwise
2. Clean the fuel filter and check the O-ring. Replace it if necessary.
3. Reassemble all parts.



1. Fuel pickup
2. Filter


ENOM00725-0

Oil filter


Oil filter and oil tank. Check the oil tank and/or filter for entrapped water and dust.

1. Disconnect all pipes between the oil tank and oil pump.
2. Clean out foreign matter.

3. Refit the pipes to the oil tank and pumps, and then fill up with new engine oil.
4. For air purging, refer to "Engine oil feeding" (See page 40)

40, 50

1. Oil filter

75, 90, 115

1. Oil filter

ENOM00098-A


Gear oil replacement

ENOW00094-0


⚠ WARNING

- Be sure that outboard motor is secured to transom or service stand, or accidental drop or fall of outboard motor could lead to severe personal injury.
- Be sure to lock outboard motor if it is tilted up, or accidental fall of outboard motor could lead to severe personal injury.
- Do not go under outboard motor tilted up and locked, or accidental fall of outboard motor could lead to severe personal injury.

1. Tilt down the outboard motor.
2. Remove the oil plugs (lower and upper), and completely drain the gear oil into a pan.


40, 50

ENOF01331-0

75, 90, 115


ENOF01332-0

3. Insert the oil tube nozzle into the lower oil plug hole, and fill with gear oil by squeezing the oil tube until oil flows out of the upper plug hole and bubbles is disappeared to remove the air.

40, 50

ENOF01333-0

75, 90, 115



ENOF01334-0


4. Install the upper oil plug, and then remove oil tube nozzle and install the lower oil plug.

ENOW00095-0

! CAUTION


Do not reuse oil plug gasket. Always use new gasket and tighten oil plug properly to prevent entry of water into lower unit.

40, 50



ENOF01331-0

75, 90, 115



ENOF01332-0

ENOW00928-0

! CAUTION

Wipe off gear oil well immediately if spilled and dispose of it in accordance with local fire prevention and environment protection regulations.

ENON00032-0

Note

If water in the oil, giving it a milky colored appearance. Contact your dealer.

ENON00033-0

Note

Use genuine gear oil or the recommended one (API GL-5: SAE #80 to #90). Required volume 40, 50: approx. 500 mL (16.9 fl.Oz), 75, 90, 115 approx. 900 ml (30.4 fl.Oz).

ENOM00086-A

Propeller replacement

ENOW00084-0

! WARNING

- Do not begin propeller removal and installation procedure with spark plug caps attached, shift in forward or reverse, main switch at other than

"OFF", engine stop switch lock attached to the switch, and starter key attached, or engine could accidentally start leading to serious personal injury. Disconnect battery cable if possible.

- The propeller edge is thin and sharp. Wear the grooves during replacement to protect your hands.


ENOF00086-0

CAUTION

- Do not install propeller without thrust holder, or propeller boss could be damaged.
- Do not reuse split pin.
- After installing split pin, spread the pin apart to prevent it from falling out which could lead to the propeller coming off during operation.

A worn-out or bent propeller will lower the motor's performance, and cause engine trouble.

1. Put a piece of wood block between propeller blade and anti-ventilation plate to hold propeller.




ENOF00084-B

2. Remove the split pin, propeller nut and washer.
3. Remove the propeller and thrust holder.

4. Apply water proof grease to the propeller shaft before installing a new propeller.
5. Install the thrust holder, propeller, stopper, washer and propeller nut onto the shaft.


40, 50



ENOF01315-0

1. Propeller
2. Thrust holder
3. Stopper
4. Washer
5. Propeller nut
6. Split pin

75, 90, 115



ENOF01336-0

1. Propeller
2. Thrust holder
3. Bush
4. Stopper
5. Washer
6. Propeller nut
7. Split pin

6. Tighten the propeller nut to specified torque, and align one of grooves to propeller shaft hole.

Propeller nut torque:

25 Nm (18 ft-lb, 2.5kgf-m)

7. Install a new split pin into the nut hole and bend it.



ENOF00084-D

ENOM00087-A

Spark plugs replacement

ENOW00087-0



WARNING

- Do not reuse spark plug with damaged insulation, or sparks can leak through crack, potentially leading to electric shock, explosion and/or fire.
- Do not touch spark plugs immediately after stopping engine as they will be hot and could cause severe burns if touched. Allow motor to cool down first.

ENOW00929-0




CAUTION

Use only the recommended spark plugs. Spark plugs which have an different heat range may cause engine damage.

If the spark plug(s) is fouled, has carbon build up, or is worn, it should be replaced. When reusing spark plugs, remove dirt from the electrodes and adjust spark gap to specification.

1. Stop the engine.
2. Remove the top cowl.
3. Remove the spark plug caps.
4. Remove the spark plugs by turning it counter-clockwise, using a 5/8" (16 mm) socket wrench and handle that is provided in tool bag.
5. Inspect the spark plug. Replace the spark plug if the electrodes are worn or if the insulators are cracked or chipped.
6. Measure the spark plug electrode gap with a wire type feeler gauge. The gap should be 0.8-0.9 mm (0.031-0.035 inches). If the gap is different, replace the spark plug with a new one
Use spark plug with referring specification (See page 13)



ENOF00085-0

1. Electrode
2. Spark gap (0.8–0.9 mm, 0.031–0.035 in)
7. Install the spark plug by hand and turn it carefully to avoid cross-threading.


8. Tighten the spark plug to the specified torque.

ENON00028-0

Note

- **Spark plug torque:**
18.0 Nm (13.3 ft-lb) [1.84 kgf-m]

If a torque-wrench is not available when you are fitting a spark plug, a good estimate of the correct torque is 1/4 to 1/2 a turn past finger-tight. Have the spark plug adjusted to the correct torque as soon as possible with a torque-wrench.



ENOF01337-0

ENOM00088-A

Anode replacement


A sacrificial anode protects the outboard motor from electrolytic corrosion. Anode is located on the gear case, cylinder etc.. When the anode is eroded more than 1/3 of original size, replace it.

ENON00029-0


Notes

- Never grease or paint the anode.
- At each inspection re-tighten the anode attaching bolt. As it is likely to be subjected to electrolytic corrosion.

75, 90, 115





40, 50




*1


75, 90, 115



75, 90



*2



*1

ENOF01339-A

*1 : Both side

*2 : Handle by your dealer

ENOM00089-B

Power Tilt oil checking

ENOW00088-0

**WARNING**

- Be sure that outboard motor is secured to transom or service stand, or accidental drop or fall of outboard motor could lead to severe personal injury.
- Be sure to lock outboard motor if it is tilted up, or accidental fall of outboard motor could lead to severe personal injury.
- Do not go under outboard motor tilted up and locked, or accidental fall of outboard motor could lead to severe personal injury.

ENOW00089-A

**CAUTION**


Do not unscrew the oil cap with the outboard motor tilted down. Pressurized oil in the oil tank may spurt out.

Check the oil level in the reservoir tank while the tank is kept in a vertical position.

1. Tilt the outboard motor up and lock the tilt with the tilt stopper.
2. Remove the oil cap by turning counter clockwise, then check if the oil level reaches the bottom line of the plug hole.


10

40, 50



1. Oil cap
2. Oil level

75, 90, 115



1. Oil cap
2. Oil level

Recommended oil

Use an automatic transmission fluid or equivalent.


Recommended oils are as shown below.

ATF Dexron III**Air purging from the Power Trim and Tilt unit.**

Entrapped air in the Power Tilt unit will cause poor tilting movement and increased noise.

1. With the outboard motor mounted on the boat, set the manual release valve to the Manual side, and tilt the outboard motor manually up/down 5-6 times while checking the oil level.
2. When done, close the valve by turning it clockwise towards the Power side.


40, 50



ENOF00070-1

1. POWER
2. MANUAL

75, 90, 115




ENOF00679-0

1. POWER
2. MANUAL

ENOM00960-0

Grease point

Apply water proof grease to the parts shown below.



ENOM00100-A

3. Off-season storage

ENOW00934-0



WARNING

- **Be sure to disconnect fuel connector except when operating engine.**
- **Fuel leakage is a fire or explosion hazard, which can cause serious injury or death.**

ENOW00097-0



WARNING

Be sure to use cloth to remove fuel remaining in the cowl and dispose of it in accordance with local fire prevention and environment protection regulations.

ENOW00096-0



CAUTION

Before servicing the motor for storage:

- **Remove the battery cables.**
- **Remove the spark plug caps from the spark plugs.**
- **Do not run the motor out of the water.**

Before you put your outboard motor in storage, it is a good opportunity to have it serviced and prepared by your dealer.

Be sure to use fuel stabilizer while running the motor before storage. (See page 92)

ENOM00101-B

Engine

1. Wash the engine exterior and flush the cooling water system thoroughly with fresh water. Drain the water completely.
Wipe off any surface water with an oily rag.

2. Remove the fuel hose from the outboard motor.
3. Drain all fuel from the fuel hoses, fuel pump, fuel filter (See page 80) and vapor separator (See page 92), and clean these parts.
Keep in mind that if gasoline is kept in the vapor separator for a long time, gum and varnish will develop, causing the float valve to stick, restricting the fuel flow.
4. Remove the spark plugs and put a teaspoon of engine oil or spray storage oil into the combustion chamber through the spark plug holes.
5. Turn the starter motor several turns to lubricate inside the cylinder.


ENOW00930-0



WARNING

- **Be sure to remove stop switch lock to prevent ignited the spark plugs.**
 - **Put a cloth to spark plug hole and wipe up any spilled engine oil, when cranking the outboard motor.**
6. Change the gear oil in the gear case (See page 82).
 7. Apply grease to grease point (See page 90).

8. Stand the outboard motor up vertically in a dry place.




ENOF01321-0

ENON00021-A

Note

- If the outboard motor must be laid down be sure drain the fuel and engine oil, then the outboard motor on a cushion as shown in the drawing below (See page 92 and 67).
- Elevate power unit 2 inches to 4 inches if traveling to avoid air intrusion in the Power Trim and Tilt pump system.



ENOF00680-0

ENOM00950-0

Adding a fuel stabilizer

When adding a fuel stabilizer additive (commercially available), first fill the fuel tank with fresh fuel. If the fuel tank is only partially filled, air in the tank can cause the fuel to deteriorate during storage.

1. Before adding fuel stabilizer additive, drain the vapor separator (See page 92).
2. Follow the instructions on the label when adding the fuel stabilizer additive.
3. After adding the additive, let the outboard motor run in the water for 10 minutes to make sure any old fuel in the fuel system has been completely replaced by the fuel with additive.
4. Turn the engine OFF

ENON00891-0

Note

If your motor is used occasionally, it is recommended to use a good fuel stabilizer in every tank of fuel and keep the container full to reduce condensation and evaporation.

ENOM00970-0

Fuel system draining

ENOW00028-A

WARNING

For details on handling fuel, contact an authorized dealer.

Fuel and fuel vapors are extremely flammable and can be explosive.

- If fuel is spilled, wipe it up immediately.
- Keep the fuel tank well away from sources of ignition, e.g. sparks or open flames
- Perform all work outdoors or in a well ventilated place.


ENOW00097-0

WARNING

Be sure to use cloth to remove fuel remaining in the cowl and dispose of it in accordance with local fire prevention and environment protection regulations.

1. Disconnect the fuel hose from the outboard motor.
2. Remove the top cowl.
3. Release the drain tube from the clamp and pull the tube outside the bottom cowl. Place an approved fuel container under the drain tube end and use a funnel to avoid spilling fuel.
4. Loosen the vapor separator drain screw.
5. Tilt up the outboard motor until fuel flows out of the drain tube.
6. Leave the outboard motor in this position until all fuel has been drained.
7. When thoroughly drained, retighten the drain screw securely.
8. Check the drained fuel for the presence of water or other contaminants. If either is present, reassemble the outboard motor, refill the vapor separator with fuel, and then drain the fuel again. Repeat this procedure until no water or other contaminants are present in the drained fuel.


40, 50



*Remove fuel filter before draining

1. Vapor separator drain screw

75, 90, 115



1. Vapor separator drain screw

ENOM00102-0

Battery

ENOW00931-A

⚠ WARNING

- Place the battery away from any source of fire, sparks and open flames such as burners or welding equipment.
- Place the battery away from fuel tank. Accidental sparks of battery may cause explosion of gasoline.

1. Disconnect the battery cables and be sure to remove the negative terminal first.
2. Wipe off any chemical deposits, dirt, or grease.
3. Apply grease to the battery terminals.
4. Charge the battery completely before storing it for the winter.
5. Recharge the battery once a month to prevent it from discharging and the electrolyte from deteriorating.
6. Store the battery in a dry place.

ENOM00104-C

4. Pre-season check

The following steps must be taken when first using the engine after off season storage.

1. Check that the shift and throttle function properly. (Be sure to turn the propeller shaft when checking the shift function or else the shift linkage may be damaged.)
2. Check the electrolyte level, and measure the voltage and specific gravity of the battery.

Specific Gravity at 20°	Terminal Voltage (V)	Charge Condition
1.120	10.5	Fully discharged
1.160	11.1	1/4 charged
1.210	11.7	1/2 charged
1.250	12	3/4 charged
1.280	13.2	Fully charged

3. Check that the battery is secure and the battery cables are properly installed.
4. Change the engine oil (See page 74).
5. Before starting the engine, disconnect stop switch lock and crank approximately 3times of 3sec. turning the starter motor in order to prime the oil pump.
6. Fill fuel tank completely.
7. Start the engine and warm up the engine for 3 minutes in the “NEUTRAL” position.
8. Run the engine for 5 minutes at the slowest speed.

9. Run the engine for 10 minutes at half throttle. The oil used for storage inside the engine will be circulated out to assure optimum performance.

ENOW00105-A

5. Submerged outboard motor

ENOW00098-0



Do not attempt to start submerged outboard motor immediately after it is recovered, or engine could be severely damaged.

After taking your outboard motor out of the water, immediately take it to your dealer.

The following are the emergency measures to be taken for a submerged outboard motor, if you can not take it your dealer right away.

1. Wash the outboard motor with fresh water to remove salt or dirt.
2. Remove the engine oil drain screw and completely drain water and oil from the engine.
3. Remove the spark plugs, and completely drain the water from the engine by pulling emergency starter rope (See page 52) several times.
Replace oil filter and oil to the correct level.
The oil and filter may need to be changed again after running a short period to get all moisture completely out of the crankcase.

4. Inject a sufficient amount of engine oil through the spark plug holes.
Pull the emergency starter rope several times to circulate the oil throughout the outboard motor.

ENOM00106-A

6. Cold weather precautions

If you moor your boat in cold weather at temperatures below 0°C (32°F), there is the danger of remained water freezing in the cooling water pump, which may damage the pump, impeller, etc. To avoid this problem, submerge the lower half of the outboard motor into the water.

ENOM00107-A

7. Striking underwater object

ENOW00935-0




CAUTION

Striking the sea bottom or an underwater object may severely damage the outboard motor.

Follow the procedure below and consult a dealer as soon as possible.

1. Stop the engine immediately.
2. Check the control system, gear case, boat transom etc.
3. Return to the nearest harbor slowly and carefully.
4. Consult a dealer check the outboard motor before operation again.



ENOF01145-0

ENOM00121-0

8. Operation with multiple outboard motors

When operating the outboard motors in reverse at more than the lowest speed, be sure that all engines are running.

If any engine has stopped, be sure to tilt the outboard motor up and keep its propeller out of the water.

Otherwise, water could enter the engine and cause damage to it.

TROUBLESHOOTING

ENOM00720-0

If you encounter problem with the engine, check the list below and locate the problem you are experiencing. Then follow the suggested remedies.

Do not hesitate to contact your dealer, as professionals advice and assistance is the best way to keep the engine in optimum condition.

Difficult to start engine	Engine runs erratically	Boat speed loss	Battery will not hold charge	Starter motor will not crank	Power Trim & Tilt Inoperative	Possible cause
●						Empty fuel tank
●	●					Incorrect connection of fuel system
●	●					Air enters fuel line
●	●					Deformed or damaged fuel pipe
●						Closed air vent on fuel tank cap
●	●					Fuel filter/fuel pump is clogged with dust.
●						Use of improper gasoline
●						Incomplete forced fuel feeling by primer bulb
●	●					Poor connection in compression system
●	●					Use of non-specified spark plugs
●	●					Dirt or carbon deposits on spark plugs
●	●					No sparking or poor sparking (Failure in component of Ignition system)
	●					Insufficient cooling water flow
	●	●				Propeller cavitation
		●				Incorrect propeller selection
	●	●				Damaged or bent propeller
		●				Unbalanced loading. Overload
		●				Transom is too high/low.
		●				Bottom of the boat is stained or damaged.
●		●				Insufficient throttle aperture.
				●	●	Battery is charged insufficiently.
●			●	●	●	Battery is nearly dead, Poor connection of battery terminal, Low level of electrolyte
					●	Power trim & tilt switch is defective.
●				●		Wrong positioning of shift lever at N (neutral) position.
●			●	●	●	Main switch in defective.

Difficult to start engine	Engine runs erratically	Boat speed loss	Battery will not hold charge	Starter motor will not crank	Power Trim & Tilt Inoperative	Possible cause
●						Lock plate is not inserted or poorly inserted into stop switch.
●			●	●	●	Wrong wiring, disconnection, poor connection.
●				●		Faulty operation of starter motor/starter solenoid
					●	A great deal of air is contained inside pump.

TOOL KIT AND SPARE PARTS

ENOM00721-0

40, 50

The following a list of the tools and spare parts provided with the motor.

Name		Quantity	Remark
Service tools	Tool bag	1	Adapter-type
	Socket wrench (16 mm)	1	
	Socket wrench (10 × 13)	1	
	Socket wrench handle	1	
	Pliers	1	
	Screwdriver (Phillips-type and flat head)	1	
Spare parts	Emergency starter rope	1	NGK IZFR6Q Diameter × Length 3 × 25 mm
	Spark plug	3	
	Split pin	1	
Parts packaged with engine	Bracket fixing bolts	4	12 mm
	Bracket fixing nuts	4	12 mm
	Washers A, B	4 each	A (large), B (small)
	Drag link	1	
	Primer bulb ASSY	1	
	Remote control box	1	
	Tachometer	1	
	Trim meter	1	
	Lead wire for meter	1	

ENOM00722-0

75, 90, 115

The following a list of the tools and spare parts provided with the motor.

Name		Quantity		Remark
		MD 75/90	MD 115	
Service tools	Tool bag	1	1	Adapter-type
	Socket wrench (16 mm)	1	1	
	Socket wrench (10 × 13)	1	1	
	Socket wrench handle	1	1	
	Pliers	1	1	
	Screwdriver (Phillips-type and flat head)	1	1	
Spare parts	Spark plug (75/90)	3		NGK IZFR6Q
	Spark plug (115)		4	NGK IZFR5J
	Split pin	1	1	Diameter × Length 3 × 25 mm
Parts packaged with engine*	Bracket fixing bolts	4	4	12 mm
	Bracket fixing nuts	4	4	12 mm
	Washers A, B	4 each	4 each	A (large), B (small)
	Drag link	1	1	
	Flushing attachment (Hose joint)	1	1	For washing
	Primer bulb ass'y	1	1	

* Fuel tank, remote control box, tachometer, trim meter, meter lead wire and propeller are not enclosed in the engine package.

PROPELLER TABLE

ENOM00724-0

To ensure optimum performance, the propeller should match the boat type and its load.

Use a genuine propeller.

A propeller must be selected so that the engine rpm measured at wide open throttle, while cruising, is within the recommended range.

5150–5850 rpm

30, 40, 50

	Pitch
Lighter load Heavier load	15
	14
	13
	12
	11
	9
	7 ^{*1}

*1: Shows propeller with four blades.

75, 90, 115^{*2}

	Pitch
Lighter load Heavier load	21
	19
	17
	15
	13
	11
	9

*2: The 75-115 model is supplied with so standard propeller. It is shipped from the factory without a propeller.

EMISSION CONTROL SYSTEM INFORMATION

ENOM01000-0

Emission Sources

Carbon monoxide, oxides of nitrogen and hydrocarbons are produced in the course of the combustion process. Controlling production of oxides of nitrogen and hydrocarbons is very important because they react to form a photochemical smog under certain conditions when subjected to sunlight. Carbon monoxide does not react in the same way, but is a toxic byproduct.

ENOM01001-0

Ignition Timing Control System

To reduce the amount of HC, CO and NO_x produced, the ignition timing control system continuously adjusts the ignition timing.

ENOM01002-1

Fuel Injection system

The Fuel Injection system relies on, multi-port fuel injection for both engine control and fuel control. The Engine Control Unit (ECU) has several sensors to determine how much fuel is needed for injection under all operating conditions.

ENOM01003-0

Clean Air Acts of the United States and California, and Environment Canada

EPA, California, and Canadian regulations require all manufacturers to provide written instructions that describe the operation and maintenance of commercial emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your engine within these emission standards.

ENOM01004-0

Tampering and Modifications

Tampering is a violation of the Federal Laws of the United States and California.

Tampering with or altering the emission control system could cause emissions to increase beyond legal limits. The following acts, although not all inclusive, are considered as tampering:

- Removing or modifying any part of the intake, fuel or exhaust system.
- Modifications that cause the engine to operate outside its design parameters.

ENOM01005-0

Problems that can affect emission

If you notice any of the following symptoms, have your outboard motor inspected and repaired by an authorized Tohatsu service dealer before further use.

- Hard starting or stalling immediately after starting
- Rough idling
- Misfiring/backfiring under load
- Afterburning (backfiring)
- Black exhaust smoke or increased fuel consumption

ENOM01006-0

Replacement Parts

The emission control system in your Tohatsu outboard motor has been designed, built, and certified to conform with the EPA and California emission regulations. Whenever requesting maintenance, use of Tohatsu Genuine parts is highly recommended. Tohatsu Genuine parts constitute replacement parts manufactured to the same high standards as the original parts, thus guaranteeing uninterrupted high performance of your outboard motor. The use of replacement parts other than Tohatsu Genuine parts could jeopardize the effectiveness of the emission control system.

Tohatsu, as a manufacturer of aftermarket parts, assumes the responsibility that replacement parts will not adversely affect emission performance. The manufacturer or rebuilder of the replacements parts must certify that use of the parts will not

result in a failure of the engine to comply with these regulations.

ENOM00033-0

Low permeation fuel hose requirement

EQUIPPED FOR UNITED STATES AND CANADA MODEL

Required for outboards manufactured for sale, sold, or offered for sale in the United States.

- TOHATSU engine has used fuel hoses for The Environmental Protection Agency (EPA) requires from January 1, 2011.

ENOM00034-A

EPA pressurized portable fuel tank requirements

EQUIPPED FOR UNITED STATES AND CANADA MODEL

The Environmental Protection Agency (EPA) required portable fuel systems that are produced after January 1, 2011 for use with outboard engines to remain fully sealed (pressurized) up to 34.4 kPa (5.0 psi). These tanks may contain the following:

- An air inlet that opens to allow air to enter as the fuel is drawn out of the tank.
- An air outlet that opens (vents) to the atmosphere if pressure exceeds 34.4 kPa (5.0 psi). A hissing noise may be heard as the tank vents to the atmosphere. This is normal.
- When installing the fuel tank cap, turn the cap to the right until you hear two clicks. This signals that the fuel cap is fully seated. A built-in device prevents overtightening.
- The fuel tank has a manual vent screw which should be closed for transportation and full open for operation and cap removal.

Since sealed fuel tanks are not openly vented, they will expand and contract as the fuel expands and contracts during heating and cooling cycles of the outside air. This is normal.

ENOM00036-0

EPA approval Primer valve/hose assembly

EQUIPPED FOR UNITED STATES AND CANADA MODEL


TOHATSU adopts Primer bulb/hose assembly approved by the Environment Protection Agency (EPA).

Please use the EPA approved primer bulb/hose assembly.

ENOW00021-0

CAUTION

Be sure to use EPA approved tank and EPA approved primer bulb/hose assembly as a set. Confirm shapes of EPA approved tank and regular tank.



ENOF00024-0

1. Except for U.S. model (regular tank)
2. For U.S. and Canada model (EPA approved tank)

ENOM01007-0


Maintenance

Follow the maintenance schedule presented on page 70. Keep in mind that this schedule is based on the assumption that the outboard motor will only be used for its intended purpose. Operation under sustained high loads or other unusual conditions will require more frequent service.

ENOM01008-0

Star label

This outboard motor is labeled with the California Air Resources Board (CARB) star label. A description of this label is presented below.



ENOF01000-0



ENOF01001-0

ENOM01009-0

One Star-Low Emission

One Star- Low emission The one-star label identifies engines that meet the Air

Resources Board's Personal Watercraft and Outboard marine engine 2001 exhaust emission standards.

Engines meeting these standards have 75% lower emissions than conventional carbureted two-stroke engines.

These engines are equivalent to the U.S. EPA's 2006 standards for marine engines.



ENOF01002-0

ENOM01010-0

Two Stars-Very Low Emission

The two-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2004 exhaust emission standards.

Engines meeting these standards have 20% lower emissions than One Star-Low Emission engines.



ENOF01003-0

ENOM01011-0

Three Stars-Ultra Low Emission

The three-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2008 exhaust emission standards or the Sterndrive and Inboard marine engine 2003-2008 exhaust emission standards.

Engines meeting these standards have 65% lower emissions than One Star-Low Emission engines.



ENOM01012-0

Four Stars-Super Ultra Low Emission

The four-star label identifies engines that meet the Air Resources Board's Sterndrive and Inboard marine engine 2009 exhaust emission standards.

Personal Watercraft and Outboard marine engines may also comply with these standards.

Engines meeting these standards have 90% lower emissions than One Star-Low Emission engines.



OWNER'S MANUAL

MD 40B2

MD 50B2

MD 75C2

MD 90C2

MD 115A2